

PENTAIR				DRW. DR150007	SPARE-PARTS																
				Select language English	SPARE-PARTS KIT TABLE																
SPARE-PARTS				PVM 1	PUMP MODEL																
RECOMME NDED PARTS KIT	N° RIF. KIT	KIT DESCRIPTION	COMPONE NT REF. Nr.	COMPONENT DESCRIPTION	PVM 1-2 F M	PVM 1-2 F T	PVM 1-3 F M	PVM 1-3 F T	PVM 1-4 F M	PVM 1-4 F T	PVM 1-5 F M	PVM 1-5 F T	PVM 1-6 F M	PVM 1-6 F T	PVM 1-7 F M						
	82	TIE ROD KIT (PUMP BODY ~)	97	NUT (TIE ROD LOCKING ~)	ZBR50680	4 pc	ZBR50690	4 pc	ZBR50700	4 pc	ZBR50710	4 pc	ZBR50720	4 pc	ZBR50730	4 pc					
			214	WASHER		4 pc		4 pc		4 pc		4 pc		4 pc							
			339	ROD		4 pc		4 pc		4 pc		4 pc		4 pc							
	200	BOLTS AND SCREWS KIT	435	SPACER	ZBR50140											1 pc					
			73	NUT												1 pc					
			273	RING (STOP ~)												1 pc					
			477	SPACER												1 pc					
	201	GASKET KIT	516	O-RING	ZBR50070 (EPDM standard) ZBR50080 (Viton)											1 pc					
			412	GASKET												3 pc					
			25	O-RING (PUMP BODY ~)												2 pc					
	374	HYDRAULIC KIT WITH BEARING	290	CHAMBER (DIFFUSER-BEARING-RING INTERM. ~)	ZBR50020											1 pc					
			487	BEARING												1 pc					
			21	IMPELLER												1 pc					
			479	SPACER												1 pc					
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR50050											1 pc					
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR49290 SUUE											1 pc					
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR49320 SQBE											1 pc					
	323	STAGE (INTERMEDIATE ~)KIT	308	CHAMBER (UPPER ~ WITH DIFFUSER)	ZBR50030											1 pc					
			21	IMPELLER												1 pc					
			478	SPACER												1 pc					
	372	HYDRAULIC KIT	21	IMPELLER	ZBR50000											1 pc					
	384	PUMP BODY KIT	288	BASE (PUMP ~)	ZBR50170											1 pc					
	402	MOTOR KIT	488	COMPLETE MOTOR	ZBR21130	1 pc	ZBR21140	1 pc	ZBR21130	1 pc	ZBR21140	1 pc	ZBR21130	1 pc	ZBR21140	1 pc	ZBR21130	1 pc			
	560	BOLTS AND SCREWS KIT	4	SCREW	ZBR50210											4 pc					
	404	SHAFT KIT	232	SHAFT	ZBR50460	1 pc	ZBR50470	1 pc	ZBR50480	1 pc	ZBR50490	1 pc	ZBR50500	1 pc	ZBR50510	1 pc					
			273	RING (STOP ~)		1 pc		1 pc		1 pc		1 pc		1 pc							
	405	COUPLING KIT	103	COUPLING (MOTOR PUMP ~)	ZBR50090											1 pc					
	406	MOTOR STOOL KIT	27	LANTERN	ZBR50180											1 pc					
	411	GUARD COUPLING KIT	274	GUARD COUPLING SCREW	ZBR50120											4 pc					
			414	GUARD COUPLING												2 pc					
	452	HYDRAULIC KIT, FIRST STAGE	286	CHAMBER (INTERMEDIATE ~ W/O DIFFUSER)	ZBR50010											1 pc					
			21	IMPELLER												1 pc					
			435	SPACER												1 pc					
	474	SLEEVE KIT	83	SLEEVE	ZBR50240	1 pc	ZBR50250	1 pc	ZBR50260	1 pc	ZBR50270	1 pc	ZBR50280	1 pc	ZBR50290	1 pc					
*	475	WEAR RINGS KIT	276	RING (GUIDE ~)	ZBR50060											1 pc					
			277	SUPPORT (GUIDE RING ~)												1 pc					
	373	HYDRAULIC KIT, LAST STAGE	11	DIFFUSER (DISCHARGE ~)	ZBR50040											1 pc					
			36	RING (ELASTIC ~)												1 pc					
	392	PLUGS WITH ORING KIT (KIT-B)	78	NOZZLE (AIR ~)	ZBR50150											1 pc					
			5	PLUG (FILL ~)												1 pc					
			412	GASKET												2 pc					
	484	RECYCLING PLUG KIT	88	SHUTTER	ZBR50160											1 pc					
			412	GASKET												1 pc					

PENTAIR				DRW. DR150007		SPARE-PARTS																				
				Select language English		SPARE-PARTS KIT TABLE																				
SPARE-PARTS				PVM 1		PUMP MODEL																				
RECOMMENDED PARTS KIT	N° RIF. KIT	KIT DESCRIPTION	COMPONENT NT REF. N°.	COMPONENT DESCRIPTION		PVM 1-7 F T	PVM 1-8 F M	PVM 1-8 F T	PVM 1-9 F M	PVM 1-9 F T	PVM 1-10 F M	PVM 1-10 F T	PVM 1-11 F M	PVM 1-11 F T	PVM 1-12 F M	PVM 1-12 F T										
	82	TIE ROD KIT (PUMP BODY –)	97	NUT (TIE ROD LOCKING –)		ZBR50730	ZBR50740	ZBR50750	ZBR50760	ZBR50770	ZBR50780															
			214	WASHER																						
			339	ROD																						
	200	BOLTS AND SCREWS KIT	435	SPACER		ZBR50140																				
			73	NUT																						
			273	RING (STOP –)																						
	201	GASKET KIT	477	SPACER		ZBR50070 (EPDM standard) ZBR50080 (Viton)																				
			516	O-RING																						
			412	GASKET																						
			25	O-RING (PUMP BODY –)		ZBR50020																				
	374	HYDRAULIC KIT WITH BEARING	290	CHAMBER (DIFFUSER-BEARING-RING INTERM. –)																						
			487	BEARING																						
			21	IMPELLER		ZBR50050																				
			479	SPACER																						
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL –)																						
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL –)		ZBR49290 SUUE																				
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL –)		ZBR49320 SQBE																				
	323	STAGE (INTERMEDIATE –)KIT	308	CHAMBER (UPPER – WITH DIFFUSER)		ZBR50030																				
			21	IMPELLER																						
			478	SPACER																						
	372	HYDRAULIC KIT	21	IMPELLER		ZBR50000 ZBR50170																				
	384	PUMP BODY KIT	288	BASE (PUMP –)																						
	402	MOTOR KIT	488	COMPLETE MOTOR																						
	560	BOLTS AND SCREWS KIT	4	SCREW		ZBR21140	ZBR21150	ZBR21160	ZBR21150	ZBR21160	ZBR21150	ZBR21160	ZBR21150	ZBR21160	ZBR21210	ZBR50900										
	404	SHAFT KIT	232	SHAFT		ZBR50210																				
			273	RING (STOP –)																						
	405	COUPLING KIT	103	COUPLING (MOTOR PUMP –)																						
	406	MOTOR STOOL KIT	27	LANTERN		ZBR50090 ZBR50180																				
	411	GUARD COUPLING KIT	274	GUARD COUPLING SCREW		ZBR50120																				
			414	GUARD COUPLING																						
	452	HYDRAULIC KIT, FIRST STAGE	286	CHAMBER (INTERMEDIATE – W/O DIFFUSER)		ZBR50010																				
			21	IMPELLER																						
			435	SPACER																						
	474	SLEEVE KIT	83	SLEEVE		ZBR50290	ZBR50300	ZBR50310	ZBR50320	ZBR50330	ZBR50340															
★	475	WEAR RINGS KIT	276	RING (GUIDE –)		ZBR50060																				
			277	SUPPORT (GUIDE RING –)																						
	373	HYDRAULIC KIT, LAST STAGE	11	DIFFUSER (DISCHARGE –)													ZBR50040									
			36	RING (ELASTIC –)																						
	392	PLUGS WITH ORING KIT (KIT-B)	78	NOZZLE (AIR –)		ZBR50150																				
			5	PLUG (FILL –)																						
			412	GASKET																						
	484	RECYCLING PLUG KIT	88	SHUTTER		ZBR50160																				
			412	GASKET																						

PENTAIR				DRW. DR150007	SPARE-PARTS																			
				Select language English	SPARE-PARTS KIT TABLE																			
SPARE-PARTS				PVM 1	PUMP MODEL																			
RECOMME NDED PARTS KIT	N° RIF. KIT	KIT DESCRIPTION	COMPONE NT REF. Nr.	COMPONENT DESCRIPTION	PVM 1-13 F M	PVM 1-13 F T	PVM 1-15 F M	PVM 1-15 F T	PVM 1-17 F M	PVM 1-17 F T	PVM 1-19 F M	PVM 1-19 F T	PVM 1-21 F M	PVM 1-21 F T	PVM 1-23 F M									
	82	TIE ROD KIT (PUMP BODY -)	97	NUT (TIE ROD LOCKING -)	ZBR50790	4 pc	ZBR50800	4 pc	ZBR50810	4 pc	ZBR50820	4 pc	ZBR50830	4 pc	ZBR50840									
			214	WASHER																				
			339	ROD																				
	200	BOLTS AND SCREWS KIT	435	SPACER	ZBR50140										1 pc									
			73	NUT											1 pc									
			273	RING (STOP -)											1 pc									
			477	SPACER											1 pc									
	201	GASKET KIT	516	O-RING	ZBR50070 (EPDM standard) ZBR50080 (Viton)										1 pc									
			412	GASKET											3 pc									
			25	O-RING (PUMP BODY -)											2 pc									
	374	HYDRAULIC KIT WITH BEARING	290	CHAMBER (DIFFUSER-BEARING-RING INTERM. -)	ZBR50020										1 pc									
			487	BEARING											1 pc									
			21	IMPELLER											1 pc									
			479	SPACER											1 pc									
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL -)	ZBR50050										1 pc									
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL -)	ZBR49290 SUUE										1 pc									
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL -)	ZBR49320 SQBE										1 pc									
	323	STAGE (INTERMEDIATE -)KIT	308	CHAMBER (UPPER - WITH DIFFUSER)	ZBR50030										1 pc									
			21	IMPELLER											1 pc									
			478	SPACER											1 pc									
	372	HYDRAULIC KIT	21	IMPELLER	ZBR50000										1 pc									
	384	PUMP BODY KIT	288	BASE (PUMP -)	ZBR50170										1 pc									
	402	MOTOR KIT	488	COMPLETE MOTOR	ZBR21210	1 pc	ZBR50900	1 pc	ZBR21210	1 pc	ZBR50900	1 pc	ZBR50910	1 pc	ZBR50920	1 pc	ZBR50910	1 pc	ZBR50920	1 pc	ZBR50910	1 pc		
	560	BOLTS AND SCREWS KIT	4	SCREW	ZBR50220										4 pc									
	404	SHAFT KIT	232	SHAFT	ZBR50570	1 pc	ZBR50580	1 pc	ZBR50590	1 pc	ZBR50600	1 pc	ZBR50610	1 pc	ZBR50620	1 pc								
			273	RING (STOP -)																				
	405	COUPLING KIT	103	COUPLING (MOTOR PUMP -)	ZBR50100										1 pc									
	406	MOTOR STOOL KIT	27	LANTERN	ZBR50190										1 pc									
	411	GUARD COUPLING KIT	274	GUARD COUPLING SCREW	ZBR50120										4 pc									
			414	GUARD COUPLING											2 pc									
	452	HYDRAULIC KIT, FIRST STAGE	286	CHAMBER (INTERMEDIATE - W/O DIFFUSER)	ZBR50010										1 pc									
			21	IMPELLER											1 pc									
			435	SPACER											1 pc									
	474	SLEEVE KIT	83	SLEEVE	ZBR50350	1 pc	ZBR50360	1 pc	ZBR50370	1 pc	ZBR50380	1 pc	ZBR50390	1 pc	ZBR50400	1 pc								
★	475	WEAR RINGS KIT	276	RING (GUIDE -)	ZBR50060										1 pc									
			277	SUPPORT (GUIDE RING -)											1 pc									
	373	HYDRAULIC KIT, LAST STAGE	11	DIFFUSER (DISCHARGE -)	ZBR50040										1 pc									
			36	RING (ELASTIC -)											1 pc									
	392	PLUGS WITH ORING KIT (KIT-B)	78	NOZZLE (AIR -)	ZBR50150										1 pc									
			5	PLUG (FILL -)											1 pc									
			412	GASKET											2 pc									
	484	RECYCLING PLUG KIT	88	SHUTTER	ZBR50160										1 pc									
			412	GASKET											1 pc									

				DRW. DR150007	SPARE-PARTS																			
				Select language English	SPARE-PARTS KIT TABLE																			
SPARE-PARTS				PVM 1	PUMP MODEL																			
RECOMME NDED PARTS KIT	N° RIF. KIT	KIT DESCRIPTION	COMPONE NT REF. Nr.	COMPONENT DESCRIPTION	PVM 1-23 F T	PVM 1-25 F M	PVM 1-25 F T	PVM 1-27 F M	PVM 1-27 F T	PVM 1-30 F M	PVM 1-30 F T	PVM 1-33 F M	PVM 1-33 F T	PVM 1-36 F M	PVM 1-36 F T									
	82	TIE ROD KIT (PUMP BODY -)	97	NUT (TIE ROD LOCKING -)	ZBR50840	ZBR50850		ZBR50860		ZBR50870		ZBR50880		ZBR50890										
			214	WASHER																				
			339	ROD																				
	200	BOLTS AND SCREWS KIT	435	SPACER	ZBR50140																			
			73	NUT																				
			273	RING (STOP -)																				
			477	SPACER																				
	201	GASKET KIT	516	O-RING	ZBR50070 (EPDM standard) ZBR50080 (Viton)																			
			412	GASKET																				
			25	O-RING (PUMP BODY -)																				
	374	HYDRAULIC KIT WITH BEARING	290	CHAMBER (DIFFUSER-BEARING-RING INTERM. -)	ZBR50020																			
			487	BEARING																				
			21	IMPELLER																				
			479	SPACER																				
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL -)	ZBR50050																			
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL -)	ZBR49290 SUUE																			
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL -)	ZBR49320 SQBE																			
	323	STAGE (INTERMEDIATE -)KIT	308	CHAMBER (UPPER - WITH DIFFUSER)	ZBR50030																			
			21	IMPELLER																				
			478	SPACER																				
	372	HYDRAULIC KIT	21	IMPELLER	ZBR50000																			
	384	PUMP BODY KIT	288	BASE (PUMP -)	ZBR50170																			
	402	MOTOR KIT	488	COMPLETE MOTOR	ZBR50920	ZBR30720	ZBR50930	ZBR30720	ZBR50930	ZBR30720	ZBR50930	ZBR50940	ZBR50950	ZBR50940	ZBR50950									
	560	BOLTS AND SCREWS KIT	4	SCREW	ZBR50220	ZBR50230																		
	404	SHAFT KIT	232	SHAFT	ZBR50620	ZBR50630	ZBR50640	ZBR50650	ZBR50660	ZBR50670														
			273	RING (STOP -)																				
	405	COUPLING KIT	103	COUPLING (MOTOR PUMP -)	ZBR50100	ZBR50110																		
	406	MOTOR STOOL KIT	27	LANTERN	ZBR50190	ZBR50200																		
	411	GUARD COUPLING KIT	274	GUARD COUPLING SCREW	ZBR50120	ZBR50130																		
			414	GUARD COUPLING																				
	452	HYDRAULIC KIT, FIRST STAGE	286	CHAMBER (INTERMEDIATE - W/O DIFFUSER)	ZBR50010																			
			21	IMPELLER																				
			435	SPACER																				
	474	SLEEVE KIT	83	SLEEVE	ZBR50400	ZBR50410	ZBR53680	ZBR53690	ZBR53700	ZBR53710														
*	475	WEAR RINGS KIT	276	RING (GUIDE -)	ZBR50060																			
			277	SUPPORT (GUIDE RING -)																				
	373	HYDRAULIC KIT, LAST STAGE	11	DIFFUSER (DISCHARGE -)	ZBR50040																			
			36	RING (ELASTIC -)																				
	392	PLUGS WITH ORING KIT (KIT B)	78	NOZZLE (AIR -)	ZBR50150																			
			5	PLUG (FILL -)																				
			412	GASKET																				
	484	RECYCLING PLUG KIT	88	SHUTTER	ZBR50160																			
			412	GASKET																				

PENTAIR				DRW. DR150007	SPARE-PARTS															
				Select language English	SPARE-PARTS KIT TABLE															
SPARE-PARTS				PVM 3	PUMP MODEL															
RECOMMENDED PARTS KIT	KIT REF. Nr.	KIT DESCRIPTION	COMPONENT REF. Nr.	COMPONENT DESCRIPTION	PVM 3-2 F M	PVM 3-2 F T	PVM 3-3 F M	PVM 3-3 F T	PVM 3-4 F M	PVM 3-4 F T	PVM 3-5 F M	PVM 3-5 F T	PVM 3-6 F M	PVM 3-6 F T						
	82	TIE ROD KIT (PUMP BODY ~)	97	NUT (TIE ROD LOCKING ~)	ZBR50680	4 pc	ZBR50690	4 pc	ZBR50700	4 pc	ZBR50710	4 pc	ZBR50720	4 pc						
214			WASHER	4 pc		4 pc		4 pc		4 pc										
339			ROD	4 pc		4 pc		4 pc		4 pc										
	200	BOLTS AND SCREWS KIT	435	SPACER	ZBR50140									1 pc						
73			NUT	1 pc																
273			RING (STOP ~)	1 pc																
477			SPACER	1 pc																
	201	GASKET KIT	516	O-RING	ZBR50070 (EPDM standard) ZBR50080 (Viton)									1 pc						
412			GASKET	3 pc																
25			O-RING (PUMP BODY ~)	2 pc																
	374	HYDRAULIC KIT WITH BEARING	290	CHAMBER (DIFFUSER-BEARING~RING INTERM. ~)	ZBR51040									1 pc						
487			BEARING	1 pc																
21			IMPELLER	1 pc																
479			SPACER	1 pc																
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR50050									1 pc						
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR49290 SUUE									1 pc						
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR49320 SQBE									1 pc						
	323	STAGE (INTERMEDIATE ~)KIT	308	CHAMBER (UPPER ~ WITH DIFFUSER)	ZBR51050									1 pc						
21			IMPELLER	1 pc																
478			SPACER	1 pc																
	372	HYDRAULIC KIT	21	IMPELLER	ZBR51020									1 pc						
	384	PUMP BODY KIT	288	BASE (PUMP ~)	ZBR50170									1 pc						
	402	MOTOR KIT	488	COMPLETE MOTOR	ZBR21130	1 pc	ZBR21140	1 pc	ZBR21130	1 pc	ZBR21140	1 pc	ZBR21130	1 pc	ZBR21140	1 pc	ZBR21150	1 pc	ZBR21160	1 pc
	560	BOLTS AND SCREWS KIT	4	SCREW	ZBR50210									4 pc						
	404	SHAFT KIT	232	SHAFT	ZBR50460	1 pc	ZBR50470	1 pc	ZBR50480	1 pc	ZBR50490	1 pc	ZBR50500	1 pc						
			273	RING (STOP ~)		1 pc		1 pc		1 pc		1 pc		1 pc						
	405	COUPLING KIT	103	COUPLING (MOTOR PUMP ~)	ZBR50090									1 pc						
	406	MOTOR STOOL KIT	27	LANTERN	ZBR50180									1 pc						
	411	GUARD COUPLING KIT	274	GUARD COUPLING SCREW	ZBR50120									4 pc						
			414	GUARD COUPLING										2 pc						
	452	HYDRAULIC KIT, FIRST STAGE	286	CHAMBER (INTERMEDIATE ~ W/O DIFFUSER)	ZBR51030									1 pc						
			21	IMPELLER										1 pc						
			435	SPACER										1 pc						
	474	SLEEVE KIT	83	SLEEVE	ZBR50240	1 pc	ZBR50250	1 pc	ZBR50260	1 pc	ZBR50270	1 pc	ZBR50280	1 pc						
★	475	WEAR RINGS KIT	276	RING (GUIDE ~)	ZBR50060									1 pc						
			277	SUPPORT (GUIDE RING ~)										1 pc						
	373	HYDRAULIC KIT, LAST STAGE	11	DIFFUSER (DISCHARGE ~)	ZBR50040									1 pc						
			36	RING (ELASTIC ~)										1 pc						
	392	PLUGS WITH ORING KIT (KIT-B)	78	NOZZLE (AIR ~)	ZBR50150									1 pc						
			5	PLUG (FILL ~)										1 pc						
			412	GASKET										2 pc						
	484	RECYCLING PLUG KIT	88	SHUTTER	ZBR50160									1 pc						
			412	GASKET										1 pc						

PENTAIR				DRW. DR150007	SPARE-PARTS												
				Select language English	SPARE-PARTS KIT TABLE												
SPARE-PARTS				PVM 3	PUMP MODEL												
RECOMMENDED PARTS KIT	KIT REF. Nr.	KIT DESCRIPTION	COMPONENT REF. Nr.	COMPONENT DESCRIPTION	PVM 3-7 F M	PVM 3-7 F T	PVM 3-8 F M	PVM 3-8 F T	PVM 3-9 F M	PVM 3-9 F T	PVM 3-10 F M	PVM 3-10 F T	PVM 3-11 F M	PVM 3-11 F T			
	82	TIE ROD KIT (PUMP BODY ~)	97	NUT (TIE ROD LOCKING ~)	ZBR50730	4 pc	ZBR50740	4 pc	ZBR50750	4 pc	ZBR50760	4 pc	ZBR50770	4 pc			
			214	WASHER		4 pc		4 pc		4 pc		4 pc					
			339	ROD		4 pc		4 pc		4 pc		4 pc					
	200	BOLTS AND SCREWS KIT	435	SPACER	ZBR50140									1 pc			
			73	NUT										1 pc			
			273	RING (STOP ~)										1 pc			
			477	SPACER										1 pc			
	201	GASKET KIT	516	O-RING	ZBR50070 (EPDM standard) ZBR50080 (Viton)									1 pc			
			412	GASKET										3 pc			
			25	O-RING (PUMP BODY ~)										2 pc			
	374	HYDRAULIC KIT WITH BEARING	290	CHAMBER (DIFFUSER-BEARING-RING INTERM. ~)	ZBR51040									1 pc			
			487	BEARING										1 pc			
			21	IMPELLER										1 pc			
			479	SPACER										1 pc			
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR50050									1 pc			
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR49290 SUUE									1 pc			
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR49320 SQBE									1 pc			
	323	STAGE (INTERMEDIATE ~)KIT	308	CHAMBER (UPPER ~ WITH DIFFUSER)	ZBR51050									1 pc			
			21	IMPELLER										1 pc			
			478	SPACER										1 pc			
	372	HYDRAULIC KIT	21	IMPELLER	ZBR51020									1 pc			
	384	PUMP BODY KIT	288	BASE (PUMP ~)	ZBR50170									1 pc			
	402	MOTOR KIT	488	COMPLETE MOTOR	ZBR21150 1 pc	ZBR21160 1 pc	ZBR21210 1 pc	ZBR50900 1 pc	ZBR21210 1 pc	ZBR50900 1 pc	ZBR21210 1 pc	ZBR50900 1 pc	ZBR50910 1 pc	ZBR50920 1 pc			
	560	BOLTS AND SCREWS KIT	4	SCREW	ZBR50210 4 pc	ZBR50220								4 pc			
	404	SHAFT KIT	232	SHAFT	ZBR50510 1 pc	ZBR50520 1 pc	ZBR50530 1 pc	ZBR50540 1 pc	ZBR50550 1 pc								
			273	RING (STOP ~)													
	405	COUPLING KIT	103	COUPLING (MOTOR PUMP ~)	ZBR50090 1 pc	ZBR50100								1 pc			
	406	MOTOR STOOL KIT	27	LANTERN	ZBR50180 1 pc	ZBR50190								1 pc			
	411	GUARD COUPLING KIT	274	GUARD COUPLING SCREW	ZBR50120									4 pc			
			414	GUARD COUPLING										2 pc			
	452	HYDRAULIC KIT, FIRST STAGE	286	CHAMBER (INTERMEDIATE ~ W/O DIFFUSER)	ZBR51030									1 pc			
			21	IMPELLER										1 pc			
			435	SPACER										1 pc			
	474	SLEEVE KIT	83	SLEEVE	ZBR50290 1 pc	ZBR50300 1 pc	ZBR50310 1 pc	ZBR50320 1 pc	ZBR50330 1 pc								
★	475	WEAR RINGS KIT	276	RING (GUIDE ~)	ZBR50060									1 pc			
			277	SUPPORT (GUIDE RING ~)										1 pc			
	373	HYDRAULIC KIT, LAST STAGE	11	DIFFUSER (DISCHARGE ~)	ZBR50040									1 pc			
			36	RING (ELASTIC ~)										1 pc			
	392	PLUGS WITH ORING KIT (KIT-B)	78	NOZZLE (AIR ~)	ZBR50150									1 pc			
			5	PLUG (FILL ~)										1 pc			
			412	GASKET										2 pc			
	484	RECYCLING PLUG KIT	88	SHUTTER	ZBR50160									1 pc			
			412	GASKET										1 pc			

PENTAIR				DRW. DR150007	SPARE-PARTS											
				Select language English	SPARE-PARTS KIT TABLE											
SPARE-PARTS				PVM 3	PUMP MODEL											
RECOMMENDED PARTS KIT	KIT REF. Nr.	KIT DESCRIPTION	COMPONENT REF. Nr.	COMPONENT DESCRIPTION	PVM 3-12 F M	PVM 3-12 F T	PVM 3-13 F M	PVM 3-13 F T	PVM 3-15 F M	PVM 3-15 F T	PVM 3-17 F M	PVM 3-17 F T	PVM 3-19 F M	PVM 3-19 F T		
	82	TIE ROD KIT (PUMP BODY ~)	97	NUT (TIE ROD LOCKING ~)	ZBR50780	4 pc	ZBR50790	4 pc	ZBR50800	4 pc	ZBR50810	4 pc	ZBR50820	4 pc		
			214	WASHER		4 pc		4 pc		4 pc		4 pc		4 pc		
			339	ROD		4 pc		4 pc		4 pc		4 pc		4 pc		
	200	BOLTS AND SCREWS KIT	435	SPACER	ZBR50140									1 pc		
			73	NUT										1 pc		
			273	RING (STOP ~)										1 pc		
			477	SPACER										1 pc		
	201	GASKET KIT	516	O-RING	ZBR50070 (EPDM standard) ZBR50080 (Viton)									1 pc		
			412	GASKET										3 pc		
			25	O-RING (PUMP BODY ~)										2 pc		
	374	HYDRAULIC KIT WITH BEARING	290	CHAMBER (DIFFUSER-BEARING-RING INTERM. ~)	ZBR51040									1 pc		
			487	BEARING										1 pc		
			21	IMPELLER										1 pc		
			479	SPACER										1 pc		
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR50050									1 pc		
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR49290 SUUE									1 pc		
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR49320 SQBE									1 pc		
	323	STAGE (INTERMEDIATE ~)KIT	308	CHAMBER (UPPER ~ WITH DIFFUSER)	ZBR51050									1 pc		
			21	IMPELLER										1 pc		
			478	SPACER										1 pc		
	372	HYDRAULIC KIT	21	IMPELLER	ZBR51020									1 pc		
	384	PUMP BODY KIT	288	BASE (PUMP ~)	ZBR50170									1 pc		
	402	MOTOR KIT	488	COMPLETE MOTOR	ZBR50910	1 pc	ZBR50920	1 pc	ZBR50910	1 pc	ZBR50920	1 pc	ZBR30720	1 pc	ZBR50930	1 pc
	560	BOLTS AND SCREWS KIT	4	SCREW	ZBR50220					4 pc	ZBR50230				4 pc	
	404	SHAFT KIT	232	SHAFT	ZBR50560	1 pc	ZBR50570	1 pc	ZBR50580	1 pc	ZBR50590	1 pc	ZBR50600	1 pc		
			273	RING (STOP ~)		1 pc		1 pc		1 pc		1 pc		1 pc		
	405	COUPLING KIT	103	COUPLING (MOTOR PUMP ~)	ZBR50100					1 pc	ZBR50110				1 pc	
	406	MOTOR STOOL KIT	27	LANTERN	ZBR50190					1 pc	ZBR50200				1 pc	
	411	GUARD COUPLING KIT	274	GUARD COUPLING SCREW	ZBR50120					4 pc	ZBR50130				4 pc	
			414	GUARD COUPLING						2 pc					2 pc	
	452	HYDRAULIC KIT, FIRST STAGE	286	CHAMBER (INTERMEDIATE ~ W/O DIFFUSER)	ZBR51030									1 pc		
			21	IMPELLER										1 pc		
			435	SPACER										1 pc		
	474	SLEEVE KIT	83	SLEEVE	ZBR50340	1 pc	ZBR50350	1 pc	ZBR50360	1 pc	ZBR50370	1 pc	ZBR50380	1 pc		
*	475	WEAR RINGS KIT	276	RING (GUIDE ~)	ZBR50060									1 pc		
			277	SUPPORT (GUIDE RING ~)										1 pc		
	373	HYDRAULIC KIT, LAST STAGE	11	DIFFUSER (DISCHARGE ~)	ZBR50040									1 pc		
			36	RING (ELASTIC ~)										1 pc		
	392	PLUGS WITH ORING KIT (KIT-B)	78	NOZZLE (AIR ~)	ZBR50150									1 pc		
			5	PLUG (FILL ~)										1 pc		
			412	GASKET										2 pc		
	484	RECYCLING PLUG KIT	88	SHUTTER	ZBR50160									1 pc		
			412	GASKET										1 pc		

PENTAIR				DRW. DR150007	SPARE-PARTS								
				Select language English	SPARE-PARTS KIT TABLE								
SPARE-PARTS				PVM 3	PUMP MODEL								
RECOMMENDED PARTS KIT	KIT REF. Nr.	KIT DESCRIPTION	COMPONENT REF. Nr.	COMPONENT DESCRIPTION	PVM 3-21 F T	PVM 3-23 F T	PVM 3-25 F T	PVM 3-27 F T	PVM 3-29 F T	PVM 3-31 F T	PVM 3-33 F T	PVM 3-36 F T	
	82	TIE ROD KIT (PUMP BODY ~)	97	NUT (TIE ROD LOCKING ~)	ZBR50830	ZBR50840	ZBR50850	ZBR50860	ZBR51160	ZBR51170	ZBR50880	ZBR50890	
			214	WASHER									
			339	ROD									
	200	BOLTS AND SCREWS KIT	435	SPACER	ZBR50140								
			73	NUT									
			273	RING (STOP ~)									
			477	SPACER									
	201	GASKET KIT	516	O-RING	ZBR50070 (EPDM standard) ZBR50080 (Viton)								
			412	GASKET									
			25	O-RING (PUMP BODY ~)									
	374	HYDRAULIC KIT WITH BEARING	290	CHAMBER (DIFFUSER-BEARING~RING INTERM. ~)	ZBR51040								
			487	BEARING									
			21	IMPELLER									
			479	SPACER									
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR50050								
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR49290 SUUE								
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR49320 SQBE								
	323	STAGE (INTERMEDIATE ~)KIT	308	CHAMBER (UPPER ~ WITH DIFFUSER)	ZBR51050								
			21	IMPELLER									
			478	SPACER									
	372	HYDRAULIC KIT	21	IMPELLER	ZBR51020								
	384	PUMP BODY KIT	288	BASE (PUMP ~)	ZBR50170								
	402	MOTOR KIT	488	COMPLETE MOTOR	ZBR50950				1 pc	ZBR50960			
	560	BOLTS AND SCREWS KIT	4	SCREW	ZBR50230				4 pc	ZBR51080			
	404	SHAFT KIT	232	SHAFT	ZBR50610	ZBR50620	ZBR50630	ZBR51110	ZBR51120	ZBR51130	ZBR51140	ZBR51150	
			273	RING (STOP ~)									
	405	COUPLING KIT	103	COUPLING (MOTOR PUMP ~)	ZBR50110				1 pc	ZBR51060			
	406	MOTOR STOOL KIT	27	LANTERN	ZBR50200				1 pc	ZBR51070			
	411	GUARD COUPLING KIT	274	GUARD COUPLING SCREW	ZBR50130								
			414	GUARD COUPLING									
	452	HYDRAULIC KIT, FIRST STAGE	286	CHAMBER (INTERMEDIATE ~ W/O DIFFUSER)	ZBR51030								
			21	IMPELLER									
			435	SPACER									
	474	SLEEVE KIT	83	SLEEVE	ZBR50390	ZBR50400	ZBR50410	ZBR53680	ZBR51090	ZBR51100	ZBR53700	ZBR53710	
★	475	WEAR RINGS KIT	276	RING (GUIDE ~)	ZBR50060								
			277	SUPPORT (GUIDE RING ~)									
	373	HYDRAULIC KIT, LAST STAGE	11	DIFFUSER (DISCHARGE ~)	ZBR50040								
			36	RING (ELASTIC ~)									
	392	PLUGS WITH ORING KIT (KIT-B)	78	NOZZLE (AIR ~)	ZBR50150								
			5	PLUG (FILL ~)									
			412	GASKET									
	484	RECYCLING PLUG KIT	88	SHUTTER	ZBR50160								
			412	GASKET									

PENTAIR				DRW. DR150007	SPARE-PARTS															
				Select language English	SPARE-PARTS KIT TABLE															
SPARE-PARTS				PVM 5	PUMP MODEL															
RECOMMENDED PARTS KIT	KIT REF. Nr.	KIT DESCRIPTION	COMPONENT REF. Nr.	COMPONENT DESCRIPTION	PVM 5-2 F M	PVM 5-2 F T	PVM 5-3 F M	PVM 5-3 F T	PVM 5-4 F M	PVM 5-4 F T	PVM 5-5 F M	PVM 5-5 F T	PVM 5-6 F M	PVM 5-6 F T						
	82	TIE ROD KIT (PUMP BODY ~)	97	NUT (TIE ROD LOCKING ~)	ZBR51710	4 pc	ZBR51720	4 pc	ZBR51730	4 pc	ZBR51740	4 pc	ZBR51750	4 pc						
			214	WASHER		4 pc		4 pc		4 pc		4 pc		4 pc						
			339	ROD		4 pc		4 pc		4 pc		4 pc		4 pc						
	200	BOLTS AND SCREWS KIT	435	SPACER	ZBR51260									1 pc						
			73	NUT										1 pc						
			273	RING (STOP ~)										1 pc						
			477	SPACER										1 pc						
	201	GASKET KIT	516	O-RING	ZBR50070 (EPDM standard) ZBR50080 (Viton)									1 pc						
			412	GASKET										3 pc						
			25	O-RING (PUMP BODY ~)										2 pc						
	374	HYDRAULIC KIT WITH BEARING	290	CHAMBER (DIFFUSER-BEARING-RING INTERM. ~)	ZBR51210									1 pc						
			487	BEARING										1 pc						
			21	IMPELLER										1 pc						
			479	SPACER										1 pc						
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR50050									1 pc						
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR49290 SUUE									1 pc						
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR49320 SQBE									1 pc						
	323	STAGE (INTERMEDIATE ~)KIT	308	CHAMBER (UPPER ~ WITH DIFFUSER)	ZBR51220									1 pc						
			21	IMPELLER										1 pc						
			478	SPACER										1 pc						
	372	HYDRAULIC KIT	21	IMPELLER	ZBR51190									1 pc						
	384	PUMP BODY KIT	288	BASE (PUMP ~)	ZBR50170									1 pc						
	402	MOTOR KIT	488	COMPLETE MOTOR	ZBR21130	1 pc	ZBR21140	1 pc	ZBR21150	1 pc	ZBR21160	1 pc	ZBR21210	1 pc	ZBR50900	1 pc	ZBR50910	1 pc	ZBR50920	1 pc
	560	BOLTS AND SCREWS KIT	4	SCREW	ZBR50210					4 pc	ZBR50220					4 pc				
	404	SHAFT KIT	232	SHAFT	ZBR51480	1 pc	ZBR51490	1 pc	ZBR51500	1 pc	ZBR51510	1 pc	ZBR51520	1 pc						
			273	RING (STOP ~)		1 pc		1 pc		1 pc		1 pc		1 pc						
	405	COUPLING KIT	103	COUPLING (MOTOR PUMP ~)	ZBR50090					1 pc	ZBR50100					1 pc				
	406	MOTOR STOOL KIT	27	LANTERN	ZBR50180					1 pc	ZBR50190					1 pc				
	411	GUARD COUPLING KIT	274	GUARD COUPLING SCREW	ZBR50120									4 pc						
			414	GUARD COUPLING										2 pc						
	452	HYDRAULIC KIT, FIRST STAGE	286	CHAMBER (INTERMEDIATE ~ W/O DIFFUSER)	ZBR51200									1 pc						
			21	IMPELLER										1 pc						
			435	SPACER										1 pc						
	474	SLEEVE KIT	83	SLEEVE	ZBR51290	1 pc	ZBR51300	1 pc	ZBR51310	1 pc	ZBR51320	1 pc	ZBR51330	1 pc						
*	475	WEAR RINGS KIT	276	RING (GUIDE ~)	ZBR51240									1 pc						
			277	SUPPORT (GUIDE RING ~)										1 pc						
	373	HYDRAULIC KIT, LAST STAGE	11	DIFFUSER (DISCHARGE ~)	ZBR51230									1 pc						
			36	RING (ELASTIC ~)										1 pc						
	392	PLUGS WITH ORING KIT (KIT-B)	78	NOZZLE (AIR ~)	ZBR50150									1 pc						
			5	PLUG (FILL ~)										1 pc						
			412	GASKET										2 pc						
	484	RECYCLING PLUG KIT	88	SHUTTER	ZBR50160									1 pc						
			412	GASKET										1 pc						

PENTAIR				DRW. DR150007		SPARE-PARTS												
				Select language English		SPARE-PARTS KIT TABLE												
SPARE-PARTS				PVM 5		PUMP MODEL												
RECOMMENDED PARTS KIT	KIT REF. Nr.	KIT DESCRIPTION	COMPONENT REF. Nr.	COMPONENT DESCRIPTION		PVM 5-7 F M	PVM 5-7 F T	PVM 5-8 F M	PVM 5-8 F T	PVM 5-9 F M	PVM 5-9 F T	PVM 5-10 F M	PVM 5-10 F T	PVM 5-11 F T	PVM 5-12 F T	PVM 5-13 F T		
	82	TIE ROD KIT (PUMP BODY ~)	97	NUT (TIE ROD LOCKING ~)		ZBR51760	4 pc	ZBR51770	4 pc	ZBR51780	4 pc	ZBR51790	4 pc	ZBR51800	4 pc	ZBR51810	4 pc	
			214	WASHER			4 pc		4 pc		4 pc		4 pc					
			339	ROD			4 pc		4 pc		4 pc		4 pc					
	200	BOLTS AND SCREWS KIT	435	SPACER		ZBR51260												1 pc
			73	NUT														1 pc
			273	RING (STOP ~)														1 pc
			477	SPACER														1 pc
	201	GASKET KIT	516	O-RING		ZBR50070 (EPDM standard) ZBR50080 (Viton)												1 pc
			412	GASKET														3 pc
			25	O-RING (PUMP BODY ~)														2 pc
	374	HYDRAULIC KIT WITH BEARING	290	CHAMBER (DIFFUSER-BEARING-RING INTERM. ~)		ZBR51210												1 pc
			487	BEARING														1 pc
			21	IMPELLER														1 pc
			479	SPACER														1 pc
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)		ZBR50050												1 pc
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)		ZBR49290 SUUE												1 pc
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)		ZBR49320 SQBE												1 pc
	323	STAGE (INTERMEDIATE ~)KIT	308	CHAMBER (UPPER ~ WITH DIFFUSER)		ZBR51220												1 pc
			21	IMPELLER														1 pc
			478	SPACER														1 pc
	372	HYDRAULIC KIT	21	IMPELLER		ZBR51190												1 pc
	384	PUMP BODY KIT	288	BASE (PUMP ~)		ZBR50170												1 pc
	402	MOTOR KIT	488	COMPLETE MOTOR		ZBR50910 1 pc	ZBR50920 1 pc	ZBR50910 1 pc	ZBR50920 1 pc	ZBR30720 1 pc	ZBR50930 1 pc	ZBR30720 1 pc	ZBR50930 1 pc	ZBR50950			1 pc	
	560	BOLTS AND SCREWS KIT	4	SCREW		ZBR50220				4 pc	ZBR50230							4 pc
	404	SHAFT KIT	232	SHAFT		ZBR51530	1 pc	ZBR51540	1 pc	ZBR51550	1 pc	ZBR51560	1 pc	ZBR51570	1 pc	ZBR51580	1 pc	
			273	RING (STOP ~)			1 pc		1 pc		1 pc		1 pc		1 pc		1 pc	
	405	COUPLING KIT	103	COUPLING (MOTOR PUMP ~)		ZBR50100				1 pc	ZBR50110							1 pc
	406	MOTOR STOOL KIT	27	LANTERN		ZBR50190				1 pc	ZBR50200							1 pc
	411	GUARD COUPLING KIT	274	GUARD COUPLING SCREW		ZBR50120				4 pc	ZBR50130							4 pc
			414	GUARD COUPLING						2 pc								2 pc
	452	HYDRAULIC KIT, FIRST STAGE	286	CHAMBER (INTERMEDIATE ~ W/O DIFFUSER)		ZBR51200												1 pc
			21	IMPELLER														1 pc
			435	SPACER														1 pc
	474	SLEEVE KIT	83	SLEEVE		ZBR51340 1 pc	ZBR51350 1 pc	ZBR51360 1 pc	ZBR51370 1 pc	ZBR51380 1 pc	ZBR51390 1 pc	ZBR51400 1 pc						
★	475	WEAR RINGS KIT	276	RING (GUIDE ~)		ZBR51240												1 pc
			277	SUPPORT (GUIDE RING ~)														1 pc
	373	HYDRAULIC KIT, LAST STAGE	11	DIFFUSER (DISCHARGE ~)		ZBR51230												1 pc
			36	RING (ELASTIC ~)														1 pc
	392	PLUGS WITH ORING KIT (KIT-B)	78	NOZZLE (AIR ~)		ZBR50150												1 pc
			5	PLUG (FILL ~)														1 pc
			412	GASKET														2 pc
	484	RECYCLING PLUG KIT	88	SHUTTER		ZBR50160												1 pc
			412	GASKET														1 pc

PENTAIR				DRW. DR150007	SPARE-PARTS																				
				Select language English	SPARE-PARTS KIT TABLE																				
SPARE-PARTS				PVM 5	PUMP MODEL																				
RECOMMENDED PARTS KIT	KIT REF. Nr.	KIT DESCRIPTION	COMPONENT REF. Nr.	COMPONENT DESCRIPTION	PVM 5-14 F T	PVM 5-15 F T	PVM 5-16 F T	PVM 5-18 F T	PVM 5-20 F T	PVM 5-22 F T	PVM 5-24 F T	PVM 5-26 F T	PVM 5-29 F T	PVM 5-32 F T	PVM 5-36 F T										
	82	TIE ROD KIT (PUMP BODY ~)	97	NUT (TIE ROD LOCKING ~)	ZBR51830	ZBR51840	ZBR51850	ZBR50860	ZBR50870	ZBR51860	ZBR50890	ZBR51870	ZBR51880	ZBR51890	ZBR51900										
			214	WASHER																					
			339	ROD																					
	200	BOLTS AND SCREWS KIT	435	SPACER	ZBR51260																				
			73	NUT																					
			273	RING (STOP ~)																					
			477	SPACER																					
	201	GASKET KIT	516	O-RING	ZBR50070 (EPDM standard) ZBR50080 (Viton)																				
			412	GASKET																					
			25	O-RING (PUMP BODY ~)																					
	374	HYDRAULIC KIT WITH BEARING	290	CHAMBER (DIFFUSER-BEARING-RING INTERM. ~)	ZBR51210																				
			487	BEARING																					
			21	IMPELLER																					
			479	SPACER																					
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR50050																				
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR49290 SUUE																				
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR49320 SQBE																				
	323	STAGE (INTERMEDIATE ~)KIT	308	CHAMBER (UPPER ~ WITH DIFFUSER)	ZBR51220																				
			21	IMPELLER																					
			478	SPACER																					
	372	HYDRAULIC KIT	21	IMPELLER	ZBR51190																				
	384	PUMP BODY KIT	288	BASE (PUMP ~)	ZBR50170																				
	402	MOTOR KIT	488	COMPLETE MOTOR	ZBR50950		ZBR50960		ZBR47010				ZBR50970												
	560	BOLTS AND SCREWS KIT	4	SCREW	ZBR50230		ZBR51080								ZBR53070										
	404	SHAFT KIT	232	SHAFT	ZBR51600	ZBR51610	ZBR51620	ZBR51630	ZBR51640	ZBR51650	ZBR51660	ZBR51670	ZBR51680	ZBR51690	ZBR51700										
	273		RING (STOP ~)																						
	405	COUPLING KIT	103	COUPLING (MOTOR PUMP ~)	ZBR50110					ZBR51060					ZBR51250										
	406	MOTOR STOOL KIT	27	LANTERN	ZBR50200					ZBR51070					ZBR51270										
	411	GUARD COUPLING KIT	274	GUARD COUPLING SCREW	ZBR50130																				
			414	GUARD COUPLING																					
	452	HYDRAULIC KIT, FIRST STAGE	286	CHAMBER (INTERMEDIATE ~ W/O DIFFUSER)	ZBR51200																				
			21	IMPELLER																					
			435	SPACER																					
	474	SLEEVE KIT	83	SLEEVE	ZBR51410	ZBR51420	ZBR51430	ZBR50420	ZBR50430	ZBR50440	ZBR50450	ZBR51440	ZBR51450	ZBR51460	ZBR51470										
*	475	WEAR RINGS KIT	276	RING (GUIDE ~)	ZBR51240																				
			277	SUPPORT (GUIDE RING ~)																					
	373	HYDRAULIC KIT, LAST STAGE	11	DIFFUSER (DISCHARGE ~)	ZBR51230																				
			36	RING (ELASTIC ~)																					
	392	PLUGS WITH ORING KIT (KIT-B)	78	NOZZLE (AIR ~)	ZBR50150																				
			5	PLUG (FILL ~)																					
			412	GASKET																					
	484	RECYCLING PLUG KIT	88	SHUTTER	ZBR50160																				
			412	GASKET																					

PENTAIR				DRW. DR150008	SPARE-PARTS																	
				Select language English	SPARE-PARTS KIT TABLE																	
SPARE-PARTS				PVM 10	PUMP MODEL																	
RECOMMENDED PARTS KIT	KIT REF. Nr.	KIT DESCRIPTION	COMPONENT REF. Nr.	COMPONENT DESCRIPTION	PVM 10-1 F M	PVM 10-1 F T	PVM 10-2 F M	PVM 10-2 F T	PVM 10-3 F M	PVM 10-3 F T	PVM 10-4 F M	PVM 10-4 F T	PVM 10-5 F T	PVM 10-6 F T								
	82	TIE ROD KIT (PUMP BODY ~)	97	NUT (TIE ROD LOCKING ~)	ZBR52680	4 pc	ZBR52690	4 pc	ZBR52700	4 pc	ZBR52710	4 pc	ZBR52720	4 pc								
			214	WASHER		4 pc		4 pc		4 pc		4 pc										
			339	ROD		4 pc		4 pc		4 pc		4 pc										
	200	BOLTS AND SCREWS KIT	435	SPACER	ZBR52250										1 pc							
			73	NUT											1 pc							
			273	RING (STOP ~)											2 pc							
			476	BUSHING											1 pc							
	201	GASKET KIT	516	O-RING	ZBR52140 (EPDM standard) ZBR52150 (Viton)										1 pc							
			412	GASKET											3 pc							
			25	O-RING (PUMP BODY ~)											2 pc							
			87	O-RING (SHUTTER ~)											1 pc							
	374	HYDRAULIC KIT WITH BEARING	290	CHAMBER (DIFFUSER-BEARING-RING INTERM. ~)	ZBR52090										1 pc							
			487	BEARING											1 pc							
			21	IMPELLER											1 pc							
			479	SPACER											1 pc							
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR52120										1 pc							
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR49300 SUUE										1 pc							
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR49330 SQBE										1 pc							
	323	STAGE (INTERMEDIATE ~)KIT	308	CHAMBER (UPPER ~ WITH DIFFUSER)	ZBR52110										1 pc							
			21	IMPELLER											1 pc							
			478	SPACER											1 pc							
	372	HYDRAULIC KIT	21	IMPELLER	ZBR51910										1 pc							
	384	PUMP BODY KIT	288	BASE (PUMP ~)	ZBR52270										1 pc							
	402	MOTOR KIT	488	COMPLETE MOTOR	ZBR21130	1 pc	ZBR21140	1 pc	ZBR21210	1 pc	ZBR50900	1 pc	ZBR50910	1 pc	ZBR50920	1 pc	ZBR30720	1 pc	ZBR50930	1 pc	ZBR50950	1 pc
	560	BOLTS AND SCREWS KIT	4	SCREW	ZBR50210		4 pc	ZBR50220		4 pc	ZBR52240										4 pc	
	404	SHAFT KIT	232	SHAFT	ZBR52520	1 pc	ZBR52530	1 pc	ZBR52540	1 pc	ZBR52550		1 pc	ZBR52560	1 pc	ZBR52570	1 pc					
			273	RING (STOP ~)		1 pc		1 pc		1 pc			1 pc		1 pc							
	405	COUPLING KIT	103	COUPLING (MOTOR PUMP ~)	ZBR52160	1 pc	ZBR52170		1 pc	ZBR52180					1 pc							
	406	MOTOR STOOL KIT	27	LANTERN	ZBR52280	1 pc	ZBR52290		1 pc	ZBR52300					1 pc							
	411	GUARD COUPLING KIT	274	GUARD COUPLING SCREW	ZBR52210	4 pc	ZBR52220					4 pc	ZBR52230		4 pc							
			414	GUARD COUPLING		2 pc						2 pc			2 pc							
	452	HYDRAULIC KIT, FIRST STAGE	21	IMPELLER	ZBR51920										1 pc							
			435	SPACER											1 pc							
			284	INTERCONNECTOR (COMPLETE SUCTION ~)											1 pc							
			249	ROD GUIDE JIG											1 pc							
			485	SPACER											1 pc							
	474	SLEEVE KIT	83	SLEEVE	ZBR52360	1 pc	ZBR52370		1 pc	ZBR52380	1 pc	ZBR52390		1 pc	ZBR52400	1 pc	ZBR52410	1 pc				
*	475	WEAR RINGS KIT	276	RING (GUIDE ~)	ZBR52130										1 pc							
			277	SUPPORT (GUIDE RING ~)											1 pc							
	373	HYDRAULIC KIT, LAST STAGE	11	DIFFUSER (DISCHARGE ~)	ZBR52100										1 pc							
			477	SPACER											1 pc							
			228	GASKET (ANTI-VIBRATION ~)											1 pc							
	392	PLUGS WITH ORING KIT (KIT-B)	78	NOZZLE (AIR ~)	ZBR50150										1 pc							
			5	PLUG (FILL ~)											1 pc							
			412	GASKET											2 pc							
	484	RECYCLING PLUG KIT	88	SHUTTER	ZBR52260										1 pc							
			87	O-RING (SHUTTER ~)											1 pc							
			412	GASKET											1 pc							
	523	TIE ROD KIT (HYDRAULIC ~)	522	ROD	ZBR51930	2 pc	ZBR51940	2 pc	ZBR51950	2 pc	ZBR51960	2 pc	ZBR51970	2 pc	ZBR51980	2 pc						
			66	SCREW		2 pc		2 pc		2 pc		2 pc		2 pc								
			71	WASHER		2 pc		2 pc		2 pc		2 pc		2 pc								

PENTAIR				DRW. DR150008	SPARE-PARTS																			
				Select language English	SPARE-PARTS KIT TABLE																			
SPARE-PARTS				PVM 10	PUMP MODEL																			
RECOMMENDED PARTS KIT	KIT REF. Nr.	KIT DESCRIPTION	COMPONENT REF. Nr.	COMPONENT DESCRIPTION	PVM 10-7 F T	PVM 10-8 F T	PVM 10-9 F T	PVM 10-10 F T	PVM 10-12 F T	PVM 10-14 F T	PVM 10-16 F T	PVM 10-18 F T	PVM 10-20 F T	PVM 10-22 F T										
	82	TIE ROD KIT (PUMP BODY ~)	97	NUT (TIE ROD LOCKING ~)	ZBR52740	ZBR52750	ZBR52760	ZBR52770	ZBR52780	ZBR52790	ZBR52800	ZBR52810	ZBR52820	ZBR52830										
			214	WASHER																				
			339	ROD																				
	200	BOLTS AND SCREWS KIT	435	SPACER	ZBR52250									1 pc										
			73	NUT										1 pc										
			273	RING (STOP ~)										2 pc										
			476	BUSHING										1 pc										
	201	GASKET KIT	516	O-RING	ZBR52140 (EPDM standard) ZBR52150 (Viton)									1 pc										
			412	GASKET										3 pc										
			25	O-RING (PUMP BODY ~)										2 pc										
			87	O-RING (SHUTTER ~)										1 pc										
	374	HYDRAULIC KIT WITH BEARING	290	CHAMBER (DIFFUSER-BEARING-RING INTERM. ~)	ZBR52090									1 pc										
			487	BEARING										1 pc										
			21	IMPELLER										1 pc										
			479	SPACER										1 pc										
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR52120									1 pc										
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR49300 SUUE									1 pc										
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR49330 SQBE									1 pc										
	323	STAGE (INTERMEDIATE ~)KIT	308	CHAMBER (UPPER ~ WITH DIFFUSER)	ZBR52110									1 pc										
			21	IMPELLER										1 pc										
			478	SPACER										1 pc										
	372	HYDRAULIC KIT	21	IMPELLER	ZBR51910									1 pc										
	384	PUMP BODY KIT	288	BASE (PUMP ~)	ZBR52270									1 pc										
	402	MOTOR KIT	488	COMPLETE MOTOR	ZBR50960			1 pc	ZBR47010		1 pc	ZBR50970		1 pc	ZBR50980		1 pc							
	560	BOLTS AND SCREWS KIT	4	SCREW	ZBR51080				4 pc	ZBR52250						4 pc								
	404	SHAFT KIT	232	SHAFT	ZBR52580	ZBR52590	ZBR52600	ZBR52610	ZBR52620	ZBR52630	ZBR52640	ZBR52650	ZBR52660	ZBR52670										
			273	RING (STOP ~)																				
	405	COUPLING KIT	103	COUPLING (MOTOR PUMP ~)	ZBR52190					1 pc	ZBR52200				1 pc									
	406	MOTOR STOOL KIT	27	LANTERN	ZBR52310					1 pc	ZBR52320				1 pc									
	411	GUARD COUPLING KIT	274	GUARD COUPLING SCREW	ZBR52230						4 pc	ZBR52240			4 pc									
			414	GUARD COUPLING							2 pc				2 pc									
	452	HYDRAULIC KIT, FIRST STAGE	21	IMPELLER	ZBR51920									1 pc										
			435	SPACER										1 pc										
			284	INTERCONNECTOR (COMPLETE SUCTION ~)										1 pc										
			249	ROD GUIDE JIG										1 pc										
			485	SPACER										1 pc										
	474	SLEEVE KIT	83	SLEEVE	ZBR52420	1 pc	ZBR52430	1 pc	ZBR52440	1 pc	ZBR52450	1 pc	ZBR52460	1 pc	ZBR52470	1 pc	ZBR52480	1 pc	ZBR52490	1 pc	ZBR52500	1 pc	ZBR52510	1 pc
★	475	WEAR RINGS KIT	276	RING (GUIDE ~)	ZBR52130										1 pc									
			277	SUPPORT (GUIDE RING ~)											1 pc									
	373	HYDRAULIC KIT, LAST STAGE	11	DIFFUSER (DISCHARGE ~)	ZBR52100										1 pc									
			477	SPACER											1 pc									
			228	GASKET (ANTI-VIBRATION ~)											1 pc									
	392	PLUGS WITH ORING KIT (KIT-B)	78	NOZZLE (AIR ~)	ZBR50150										1 pc									
			5	PLUG (FILL ~)											1 pc									
			412	GASKET											2 pc									
	484	RECYCLING PLUG KIT	88	SHUTTER	ZBR52260										1 pc									
			87	O-RING (SHUTTER ~)											1 pc									
			412	GASKET											1 pc									
	523	TIE ROD KIT (HYDRAULIC ~)	522	ROD	ZBR51990	ZBR52000	ZBR52010	ZBR52020	ZBR52030	ZBR52040	ZBR52050	ZBR52060	ZBR52070	ZBR52080	2 pc									
			66	SCREW											2 pc									
			71	WASHER											2 pc									

PENTAIR				DRW. DR150008	SPARE-PARTS																										
				Select language English	SPARE-PARTS KIT TABLE																										
SPARE-PARTS				PVM 15	PUMP MODEL																										
RECOMMENDED PARTS KIT	KIT REF. Nr.	KIT DESCRIPTION	COMPONENT REF. Nr.	COMPONENT DESCRIPTION	PVM 15-1 F M	PVM 15-1 F T	PVM 15-2 F T	PVM 15-3 F T	PVM 15-4 F T	PVM 15-5 F T	PVM 15-6 F T	PVM 15-7 F T	PVM 15-8 F T	PVM 15-9 F T	PVM 15-10 F T	PVM 15-12 F T	PVM 15-14 F T	PVM 15-17 F T													
	82	TIE ROD KIT (PUMP BODY ~)	97	NUT (TIE ROD LOCKING ~)	ZBR53350																										
			214	WASHER			ZBR53360	ZBR53370	ZBR53380	ZBR53390	ZBR53400	ZBR53410	ZBR53420	ZBR53430	ZBR53440	ZBR53450	ZBR53460	ZBR53470													
			339	ROD																											
	200	BOLTS AND SCREWS KIT	435	SPACER	ZBR52250																										
			73	NUT																											
			273	RING (STOP ~)																											
			476	BUSHING																											
	201	GASKET KIT	516	O-RING	ZBR52140 (EPDM standard) ZBR52150 (Viton)																										
			412	GASKET																											
			25	O-RING (PUMP BODY ~)																											
			87	O-RING (SHUTTER ~)																											
	374	HYDRAULIC KIT WITH BEARING	290	CHAMBER (DIFFUSER-BEARING-RING INTERM. ~)	ZBR52990																										
			487	BEARING																											
			21	IMPELLER																											
			479	SPACER																											
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR52120																										
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR49300 SUUE																										
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR49330 SQBE																										
	323	STAGE (INTERMEDIATE ~)KIT	308	CHAMBER (UPPER ~ WITH DIFFUSER)	ZBR53010																										
			21	IMPELLER																											
			478	SPACER																											
	372	HYDRAULIC KIT	21	IMPELLER	ZBR52840																										
	384	PUMP BODY KIT	288	BASE (PUMP ~)	ZBR53040																										
	402	MOTOR KIT	488	COMPLETE MOTOR	ZBR50910	ZBR50920	ZBR50950	ZBR50960	ZBR47010	ZBR50970	ZBR50980	ZBR50990	ZBR51010																		
	560	BOLTS AND SCREWS KIT	4	SCREW	ZBR50220	ZBR53060	ZBR51080	ZBR53070	ZBR53080																						
	404	SHAFT KIT	232	SHAFT	ZBR53220	ZBR53230	ZBR53240	ZBR53250	ZBR53260	ZBR53270	ZBR53280	ZBR53290	ZBR53300	ZBR53310	ZBR53320	ZBR53330	ZBR53340														
			273	RING (STOP ~)																											
	405	COUPLING KIT	103	COUPLING (MOTOR PUMP ~)	ZBR52170	ZBR52180	ZBR52190	ZBR52200	ZBR53030																						
	406	MOTOR STOOL KIT	27	LANTERN	ZBR52290	ZBR52300	ZBR52310	ZBR52320	ZBR53050																						
	411	GUARD COUPLING KIT	274	GUARD COUPLING SCREW	ZBR52220		ZBR52230						ZBR52240																		
			414	GUARD COUPLING																											
	452	HYDRAULIC KIT, FIRST STAGE	21	IMPELLER	ZBR52850																										
			435	SPACER																											
			284	INTERCONNECTOR (COMPLETE SUCTION ~)																											
			249	ROD GUIDE JIG																											
			485	SPACER																											
	474	SLEEVE KIT	83	SLEEVE	ZBR53090	ZBR53100	ZBR53110	ZBR53120	ZBR53130	ZBR53140	ZBR53150	ZBR53160	ZBR53170	ZBR53180	ZBR53190	ZBR53200	ZBR53210														
★	475	WEAR RINGS KIT	276	RING (GUIDE ~)	ZBR53020																										
			277	SUPPORT (GUIDE RING ~)																											
	373	HYDRAULIC KIT, LAST STAGE	11	DIFFUSER (DISCHARGE ~)	ZBR53000																										
			477	SPACER																											
			228	GASKET (ANTI-VIBRATION ~)																											
	392	PLUGS WITH ORING KIT (KIT-B)	78	NOZZLE (AIR ~)	ZBR50150																										
			5	PLUG (FILL ~)																											
			412	GASKET																											
	484	RECYCLING PLUG KIT	88	SHUTTER	ZBR52260																										
			87	O-RING (SHUTTER ~)																											
			412	GASKET																											
	523	TIE ROD KIT (HYDRAULIC ~)	522	ROD	ZBR52860	ZBR52870	ZBR52880	ZBR52890	ZBR52900	ZBR52910	ZBR52920	ZBR52930	ZBR52940	ZBR52950	ZBR52960	ZBR52970	ZBR52980														
			66	SCREW																											
			71	WASHER																											

PENTAIR				DRW. DR150008	SPARE-PARTS																							
				Select language English	SPARE-PARTS KIT TABLE																							
SPARE-PARTS				PVM 20	PUMP MODEL																							
RECOMMENDED PARTS KIT	KIT REF. Nr.	KIT DESCRIPTION	COMPONENT REF. Nr.	COMPONENT DESCRIPTION	PVM 20-1 F M	PVM 20-1 F T	PVM 20-2 F T	PVM 20-3 F T	PVM 20-4 F T	PVM 20-5 F T	PVM 20-6 F T	PVM 20-7 F T	PVM 20-8 F T	PVM 20-10 F T	PVM 20-12 F T	PVM 20-14 F T	PVM 20-17 F T											
	82	TIE ROD KIT (PUMP BODY ~)	97	NUT (TIE ROD LOCKING ~)	ZBR53350	4 pc	ZBR53360	4 pc	ZBR53370	4 pc	ZBR53380	4 pc	ZBR53390	4 pc	ZBR53400	4 pc	ZBR53410	4 pc	ZBR53420	4 pc	ZBR53440	4 pc	ZBR53450	4 pc	ZBR53460	4 pc	ZBR53470	4 pc
214			WASHER	4 pc		4 pc	4 pc	4 pc	4 pc	4 pc	4 pc	4 pc	4 pc	4 pc	4 pc	4 pc	4 pc	4 pc	4 pc									
339			ROD	4 pc		4 pc	4 pc	4 pc	4 pc	4 pc	4 pc	4 pc	4 pc	4 pc	4 pc	4 pc	4 pc	4 pc	4 pc									
	200	BOLTS AND SCREWS KIT	435	SPACER	ZBR52250													1 pc										
73			NUT	1 pc																								
273			RING (STOP ~)	2 pc																								
476			BUSHING	1 pc																								
	201	GASKET KIT	516	O-RING	ZBR52140 (EPDM standard) ZBR52150 (Viton)													1 pc										
412			GASKET	3 pc																								
25			O-RING (PUMP BODY ~)	2 pc																								
87			O-RING (SHUTTER ~)	1 pc																								
	374	HYDRAULIC KIT WITH BEARING	290	HAMBER (DIFFUSER-BEARING-RING INTERM.	ZBR53500													1 pc										
487			BEARING	1 pc																								
21			IMPELLER	1 pc																								
479			SPACER	1 pc																								
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR52120 ZBR49300 SUUE ZBR49330 SQBE													1 pc										
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)														1 pc										
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)														1 pc										
	323	STAGE (INTERMEDIATE ~)KIT	308	CHAMBER (UPPER ~ WITH DIFFUSER)	ZBR53510													1 pc										
21			IMPELLER	1 pc																								
478			SPACER	1 pc																								
	372	HYDRAULIC KIT	21	IMPELLER	ZBR53480 ZBR53040													1 pc										
	384	PUMP BODY KIT	288	BASE (PUMP ~)														1 pc										
	402	MOTOR KIT	488	COMPLETE MOTOR														ZBR50910	1 pc	ZBR50920	1 pc	ZBR50950	1 pc	ZBR47010	1 pc	ZBR50970	1 pc	ZBR50980
	560	BOLTS AND SCREWS KIT	4	SCREW	ZBR50220	4 pc	ZBR53060	4 pc	ZBR51080	4 pc	ZBR53070				4 pc	ZBR53080							4 pc					
	404	SHAFT KIT	232	SHAFT	ZBR53220	1 pc	ZBR53230	1 pc	ZBR53240	1 pc	ZBR53250	1 pc	ZBR53260	1 pc	ZBR53270	1 pc	ZBR53280	1 pc	ZBR53290	1 pc	ZBR53310	1 pc	ZBR53320	1 pc	ZBR53330	1 pc	ZBR53340	1 pc
			273	RING (STOP ~)		1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc
	405	COUPLING KIT	103	COUPLING (MOTOR PUMP ~)	ZBR52170	1 pc	ZBR52180	1 pc	ZBR52190	1 pc	ZBR52200				1 pc	ZBR53030							1 pc					
	406	MOTOR STOOL KIT	27	LANTERN	ZBR52290	1 pc	ZBR52300	1 pc	ZBR52310	1 pc	ZBR52320	1 pc	ZBR53520		1 pc	ZBR53050		1 pc	ZBR53550						1 pc			
	411	GUARD COUPLING KIT	274	GUARD COUPLING SCREW	ZBR52210	4 pc	ZBR52220				4 pc	ZBR52230				4 pc	ZBR52240				4 pc				4 pc			
			414	GUARD COUPLING		2 pc					2 pc																	
	452	HYDRAULIC KIT, FIRST STAGE	21	IMPELLER	ZBR53490													1 pc										
			435	SPACER														1 pc										
			284	INTERCONNECTOR (COMPLETE SUCTION ~)														1 pc										
			249	ROD GUIDE JIG														1 pc										
			485	SPACER														1 pc										
	474	SLEEVE KIT	83	SLEEVE	ZBR53090	1 pc	ZBR53100	1 pc	ZBR53110	1 pc	ZBR53120	1 pc	ZBR53130	1 pc	ZBR53140	1 pc	ZBR53150	1 pc	ZBR53160	1 pc	ZBR53180	1 pc	ZBR53190	1 pc	ZBR53200	1 pc	ZBR53210	1 pc
★	475	WEAR RINGS KIT	276	RING (GUIDE ~)	ZBR53020													1 pc										
			277	SUPPORT (GUIDE RING ~)														1 pc										
	373	HYDRAULIC KIT, LAST STAGE	11	DIFFUSER (DISCHARGE ~)	ZBR53000													1 pc										
			477	SPACER														1 pc										
			228	GASKET (ANTI-VIBRATION ~)														1 pc										
	392	PLUGS WITH ORING KIT (KIT-B)	78	NOZZLE (AIR ~)	ZBR50150													1 pc										
			5	PLUG (FILL ~)														1 pc										
			412	GASKET														2 pc										

PENTAIR				DRW. DR150009		SPARE-PARTS													
				Select language		SPARE-PARTS KIT TABLE													
				English															
SPARE-PARTS				PVM 32		PUMP MODEL													
RECOMMENDED PARTS KIT	KIT REF. Nr.	KIT DESCRIPTION	COMPONENT REF. Nr.	COMPONENT DESCRIPTION	PVM 32-1.1 F M	PVM 32-1.1 F T	PVM 32-1 F T	PVM 32-2.2 F T	PVM 32-2 F T	PVM 32-3.2 F T	PVM 32-3 F T	PVM 32-4.2 F T	PVM 32-4 F T	PVM 32-5.2 F T	PVM 32-5 F T	PVM 32-6.2 F T	PVM 32-6 F T	PVM 32-7.2 F T	PVM 32-7 F T
	82	TIE ROD KIT (PUMP BODY -)	97	NUT (TIE ROD LOCKING -)	ZBR54210			4 pc		4 pc		4 pc		4 pc		4 pc		4 pc	
			214	WASHER															
			239	ROD															
			463	FLANGE															
	453	SUPPORT FLANGE KIT	36	RING (ELASTIC -)	ZBR53920														
			516	O-RING															
			412	GASKET															
	201	GASKET KIT	228	GASKET (ANTI-VIBRATION -)															
			25	O-RING (PUMP BODY -)	ZBR53650 (EPDM standard)														
			290	CHAMBER (DIFFUSER-BEARING-RING INTERM. -)															
			273	RING (STOP -)															
			276	RING (GUIDE -)															
			277	SUPPORT (GUIDE RING -)	ZBR53610 (with Standard impeller) ZBR54510 (with reduced impeller)														
			487	BEARING															
			21	IMPELLER															
			319	BUSHING (CONIC -)															
			73	NUT	ZBR53600 (with Standard impeller) ZBR54500 (with reduced impeller)														
			308	CHAMBER (UPPER - WITH DIFFUSER)															
			273	RING (STOP -)															
			276	RING (GUIDE -)															
			277	SUPPORT (GUIDE RING -)	ZBR53600 (with Standard impeller) ZBR54500 (with reduced impeller)														
			21	IMPELLER															
			319	BUSHING (CONIC -)															
			73	NUT															
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL -)	ZBR53630														
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL -)	ZBR49310 SUUE														
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL -)	ZBR49340 SQBE														
	373	HYDRAULIC KIT, LAST STAGE	11	DIFFUSER (DISCHARGE -)	ZBR53620														
	372	HYDRAULIC KIT	21	IMPELLER	ZBR53570														
	578	HYDRAULIC KIT	577	REDUCED IMPELLER	ZBR53580	1 pc	-	ZBR53570	1 pc	-	ZBR53570	1 pc	-	ZBR53580	1 pc	-	ZBR53580	1 pc	-
	384	PUMP BODY KIT	288	REDUCED IMPELLER	ZBR53580	1 pc	-	ZBR53580	1 pc	-	ZBR53580	1 pc	-	ZBR53580	1 pc	-	ZBR53580	1 pc	-
	402	MOTOR KIT	408	COMPLETE MOTOR	ZBR30720	1 pc	ZBR50930	1 pc	ZBR50950	1 pc	ZBR50960	1 pc	ZBR47010	1 pc	ZBR50970	1 pc	ZBR50980	1 pc	ZBR50990
			109	NUT (MOTOR LOCKING -)	ZBR30720	1 pc	ZBR50930	1 pc	ZBR50950	1 pc	ZBR50960	1 pc	ZBR47010	1 pc	ZBR50970	1 pc	ZBR50980	1 pc	ZBR50990
			4	SCREW				4 pc					4 pc					4 pc	
			107	SCREW (MOTOR LOCKING - / INTERNAL SUPPORT)				4 pc					4 pc					4 pc	
			71	WASHER															
			105	SCREW															
	404	SHAFT KIT	232	SHAFT	ZBR54070	1 pc		ZBR54080	1 pc		ZBR54090	1 pc	ZBR54100	1 pc	ZBR54110	1 pc	ZBR54120	1 pc	ZBR54130
			108	WASHER (TOOTHED -)	ZBR53910														
			92	WASHER															
			413	SCREW															
			476	BUSHING															
			278	RING (BEARING -)	ZBR53910														
			165	WASHER (BEARING LOCK -)															
			158	SCREW (STOP -)															
	405	COUPLING KIT	103	COUPLING (MOTOR PUMP -)	ZBR53720	1 pc		ZBR53730	1 pc		ZBR53740	1 pc		ZBR53750	1 pc				
	356	MOTOR COMPLETE KIT	289	MOTOR (COMPLETE - W / IMPELLER)	ZBR53800														
			228	GASKET (ANTI-VIBRATION -)	ZBR53800														
	406	MOTOR STOOL KIT	27	LAINTER				1 pc					1 pc						
			107	SCREW (MOTOR LOCKING - / INTERNAL SUPPORT)	ZBR53850	1 pc		ZBR53860	1 pc		ZBR53870	1 pc		ZBR53880	1 pc				
			274	GUARD COUPLING SCREW				4 pc					4 pc						
	411	GUARD COUPLING KIT	414	GUARD COUPLING	ZBR53790														
			21	IMPELLER	ZBR53590 (with Standard impeller) ZBR54490 (with reduced impeller)														
			273	RING (STOP -)															
			276	RING (GUIDE -)															
			277	SUPPORT (GUIDE RING -)															
			319	BUSHING (CONIC -)	ZBR53590 (with Standard impeller) ZBR54490 (with reduced impeller)														
			73	NUT															
			284	INTERCONNECTOR (COMPLETE SUCTION -)															
	474	SLEEVE KIT	83	SLEEVE	ZBR53930	1 pc		ZBR53940	1 pc		ZBR53950	1 pc	ZBR53960	1 pc	ZBR53970	1 pc	ZBR53980	1 pc	ZBR53990
			276	RING (GUIDE -)	ZBR53640														
			92	WASHER															
			277	SUPPORT (GUIDE RING -)															
			273	RING (STOP -)															
	392	PLUGS WITH ORING KIT (KIT-B)	78	NOZZLE (AIR -)	ZBR53660														
			5	PLUG (FILL -)	ZBR53660														
			622	ROD	ZBR54350														
			66	SCREW															
			92	WASHER															
	523	TIE ROD KIT (HYDRAULIC -)	92	WASHER															

PENTAIR				DRW. DR150009		SPARE-PARTS											
				Select language English		SPARE-PARTS KIT TABLE											
SPARE-PARTS				PVM 45		PUMP MODEL											
RECOMMENDED PARTS KIT	KIT REF. Nr.	KIT DESCRIPTION	COMPONENT REF. Nr.	COMPONENT DESCRIPTION	PVM 45-1-1 F T	PVM 45-1 F T	PVM 45-2-2 F T	PVM 45-2 F T	PVM 45-3-2 F T	PVM 45-3 F T	PVM 45-4-2 F T	PVM 45-4 F T	PVM 45-5-2 F T	PVM 45-5 F T	PVM 45-6-2 F T	PVM 45-6 F T	
	82	TIE ROD KIT (PUMP BODY ~)	97	NUT (TIE ROD LOCKING ~)	ZBR54970	4 pc	ZBR54980	4 pc	ZBR54990	4 pc	ZBR55000	4 pc	ZBR55010	4 pc	ZBR55020	4 pc	
			214	WASHER		4 pc		4 pc		4 pc		4 pc		4 pc		4 pc	
			339	ROD		4 pc		4 pc		4 pc		4 pc		4 pc		4 pc	
	453	SUPPORT FLANGE KIT	463	FLANGE	ZBR54700												2 pc
			36	RING (ELASTIC ~)													2 pc
	201	GASKET KIT	516	O-RING	ZBR54620 (EPDM standard)												1 pc
			412	GASKET													6 pc
			228	GASKET (ANTI-VIBRATION ~)													4 pc
			25	O-RING (PUMP BODY ~)													2 pc
	374	HYDRAULIC KIT WITH BEARING	290	CHAMBER (DIFFUSER-BEARING-RING INTERM. ~)	ZBR54580 (with Standard impeller) ZBR54590 (with reduced impeller)												1 pc
			273	RING (STOP ~)													1 pc
			276	RING (GUIDE ~)													1 pc
			277	SUPPORT (GUIDE RING ~)													1 pc
			487	BEARING													1 pc
			21	IMPELLER													1 pc
			319	BUSHING (CONIC ~)													1 pc
			73	NUT													1 pc
	323	STAGE (INTERMEDIATE ~)KIT	308	CHAMBER (UPPER ~ WITH DIFFUSER)	ZBR54560 (with Standard impeller) ZBR54570 (with reduced impeller)												1 pc
			273	RING (STOP ~)													1 pc
			276	RING (GUIDE ~)													1 pc
			277	SUPPORT (GUIDE RING ~)													1 pc
			21	IMPELLER													1 pc
			319	BUSHING (CONIC ~)													1 pc
			73	NUT													1 pc
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR53630												1 pc
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR49310 SUUE												1 pc
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR49340 SQBE												1 pc
	373	HYDRAULIC KIT, LAST STAGE	11	DIFFUSER (DISCHARGE ~)	ZBR54600												1 pc
	372	HYDRAULIC KIT	21	IMPELLER	-	ZBR54520 1 pc	-	-	ZBR54530 1 pc	-	ZBR54530 1 pc	-	ZBR54530 1 pc	-	ZBR54530 1 pc	-	
	578	HYDRAULIC KIT	577	REDUCED IMPELLER	ZBR54530 1 pc	-	ZBR54530 1 pc	-	ZBR54530 1 pc	-	ZBR54530 1 pc	-	ZBR54530 1 pc	-	ZBR54530 1 pc	-	
	384	PUMP BODY KIT	288	BASE (PUMP ~)	ZBR54690												1 pc
	402	MOTOR KIT	488	COMPLETE MOTOR	ZBR50960 1 pc	ZBR47010 1 pc	ZBR50970 1 pc	ZBR50980 1 pc	ZBR50990 1 pc	ZBR51010 1 pc	ZBR47660	ZBR51000					
	560	BOLTS AND SCREWS KIT	109	NUT (MOTOR LOCKING ~)	ZBR54650	4 pc	ZBR54660	4 pc	ZBR54670								4 pc
			4	SCREW		4 pc		4 pc									4 pc
			107	SCREW (MOTOR LOCKING ~ / INTERNAL SUPPORT)		4 pc		4 pc									4 pc
			71	WASHER													
			105	SCREW													
	404	SHAFT KIT	232	SHAFT	ZBR54840 1 pc	ZBR54850 1 pc	ZBR54860 1 pc	ZBR54870 1 pc	ZBR54880 1 pc	ZBR54890							
	341	BEARING KIT	108	WASHER (TOOTHED ~)	ZBR53910												1 pc
			92	WASHER													1 pc
			413	SCREW													1 pc
			476	BUSHING													1 pc
			278	RING (BEARING ~)													1 pc
			165	WASHER (BEARING LOCK ~)													1 pc
			158	SCREW (STOP ~)													1 pc
	405	COUPLING KIT	103	COUPLING (MOTOR PUMP ~)	ZBR53730 1 pc	ZBR53740 1 pc	ZBR53750 1 pc								ZBR53760	1 pc	
	356	MOTOR COMPLETE KIT	289	MOTOR (COMPLETE ~ W / IMPELLER)	ZBR54640												1 pc
			228	GASKET (ANTI-VIBRATION ~)													4 pc
	406	MOTOR STOOL KIT	27	LANTERN	ZBR53860	1 pc	ZBR53870	1 pc	ZBR53880								1 pc
			107	SCREW (MOTOR LOCKING ~ / INTERNAL SUPPORT)		4 pc		4 pc									4 pc
	411	GUARD COUPLING KIT	274	GUARD COUPLING SCREW	ZBR53780						ZBR53790						4 pc
			414	GUARD COUPLING													2 pc
	452	HYDRAULIC KIT, FIRST STAGE	21	IMPELLER	ZBR54540 (with Standard impeller) ZBR54550 (with reduced impeller)												1 pc
			273	RING (STOP ~)													1 pc
			276	RING (GUIDE ~)													1 pc
			277	SUPPORT (GUIDE RING ~)													1 pc
			319	BUSHING (CONIC ~)													1 pc
			73	NUT													1 pc
			284	INTERCONNECTOR (COMPLETE SUCTION ~)													1 pc
	474	SLEEVE KIT	83	SLEEVE	ZBR54710 1 pc	ZBR54720 1 pc	ZBR54730 1 pc	ZBR54740 1 pc	ZBR54750 1 pc	ZBR54760							
★	475	WEAR RINGS KIT	276	RING (GUIDE ~)	ZBR54610												1 pc
			277	SUPPORT (GUIDE RING ~)													1 pc
			273	RING (STOP ~)													1 pc
	392	PLUGS WITH ORING KIT (KIT-B)	78	NOZZLE (AIR ~)	ZBR53660												1 pc
			5	PLUG (FILL ~)													5 pc
	523	TIE ROD KIT (HYDRAULIC ~)	522	ROD	ZBR55210	2 pc	ZBR55220	2 pc	ZBR55230	2 pc	ZBR55240	2 pc	ZBR55250	2 pc	ZBR55260	2 pc	
			66	SCREW		2 pc		2 pc		2 pc		2 pc		2 pc		2 pc	
			92	WASHER		2 pc		2 pc		2 pc		2 pc		2 pc		2 pc	

PENTAIR				DRW. DR150009	SPARE-PARTS												
				Select language English	SPARE-PARTS KIT TABLE												
SPARE-PARTS				PVM 45	PUMP MODEL												
RECOMMENDED PARTS KIT	KIT REF. Nr.	KIT DESCRIPTION	COMPONENT REF. Nr.	COMPONENT DESCRIPTION	PVM 45-7-2 F T	PVM 45-7 F T	PVM 45-8-2 F T	PVM 45-8 F T	PVM 45-9-2 F T	PVM 45-9 F T	PVM 45-10-2 F T	PVM 45-10 F T	PVM 45-11-2 F T	PVM 45-11 F T	PVM 45-12-2 F T	PVM 45-12 F T	PVM 45-13-2 F T
	82	TIE ROD KIT (PUMP BODY ~)	97 214 339	NUT (TIE ROD LOCKING ~) WASHER ROD	ZBR55030		ZBR55040		ZBR55050		ZBR55060		ZBR55070		ZBR55080		ZBR55200
	453	SUPPORT FLANGE KIT	463 36	FLANGE RING (ELASTIC ~)	ZBR54700												
	201	GASKET KIT	516 412 228 25	O-RING GASKET GASKET (ANTI-VIBRATION ~) O-RING (PUMP BODY ~)	ZBR54620 (EPDM standard)												
	374	HYDRAULIC KIT WITH BEARING	290 273 276 277 487 21 319 73	CHAMBER (DIFFUSER-BEARING-RING INTERM. ~) RING (STOP ~) RING (GUIDE ~) SUPPORT (GUIDE RING ~) BEARING IMPELLER BUSHING (CONIC ~) NUT	ZBR54580 (with Standard impeller) ZBR54590 (with reduced impeller)												
	323	STAGE (INTERMEDIATE ~)KIT	308 273 276 277 21 319 73	CHAMBER (UPPER ~ WITH DIFFUSER) RING (STOP ~) RING (GUIDE ~) SUPPORT (GUIDE RING ~) IMPELLER BUSHING (CONIC ~) NUT	ZBR54560 (with Standard impeller) ZBR54570 (with reduced impeller)												
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR53630												
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR49310 SUUE												
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR49340 SQBE												
	373	HYDRAULIC KIT, LAST STAGE	11	DIFFUSER (DISCHARGE ~)	ZBR54600												
	372	HYDRAULIC KIT	21	IMPELLER	ZBR54520												
	578	HYDRAULIC KIT	577	REDUCED IMPELLER	ZBR54530	-	ZBR54530	-	ZBR54530	-	ZBR54530	-	ZBR54530	-	ZBR54530	-	ZBR54530
	384	PUMP BODY KIT	288	BASE (PUMP ~)	ZBR54690												
	402	MOTOR KIT	488	COMPLETE MOTOR	ZBR51180				ZBR55340				ZBR55350				
	560	BOLTS AND SCREWS KIT	109 4 107 71 105	NUT (MOTOR LOCKING ~) SCREW SCREW (MOTOR LOCKING ~ / INTERNAL SUPPORT) WASHER SCREW	ZBR54670												
	404	SHAFT KIT	232	SHAFT	ZBR54900	ZBR54910	ZBR54920	ZBR54930	ZBR54940	ZBR54950	ZBR54960						
	341	BEARING KIT	108 92 413 476 278 165 158	WASHER (TOOTHED ~) WASHER SCREW BUSHING RING (BEARING ~) WASHER (BEARING LOCK ~) SCREW (STOP ~)	ZBR53910												
	405	COUPLING KIT	103	COUPLING (MOTOR PUMP ~)	ZBR54630												
	356	MOTOR COMPLETE KIT	289 228	MOTOR (COMPLETE ~ W / IMPELLER) GASKET (ANTI-VIBRATION ~)	ZBR54640												
	406	MOTOR STOOL KIT	27 107	LANTERN SCREW (MOTOR LOCKING ~ / INTERNAL SUPPORT)	ZBR53890				ZBR54680								
	411	GUARD COUPLING KIT	274 414	GUARD COUPLING SCREW GUARD COUPLING	ZBR53790												
	452	HYDRAULIC KIT, FIRST STAGE	21 273 276 277 319 73 284	IMPELLER RING (STOP ~) RING (GUIDE ~) SUPPORT (GUIDE RING ~) BUSHING (CONIC ~) NUT INTERCONNECTOR (COMPLETE SUCTION ~)	ZBR54540 (with Standard impeller) ZBR54550 (with reduced impeller)												
	474	SLEEVE KIT	83	SLEEVE	ZBR54770	ZBR54780	ZBR54790	ZBR54800	ZBR54810	ZBR54820	ZBR54830						
*	475	WEAR RINGS KIT	276 277 273	RING (GUIDE ~) SUPPORT (GUIDE RING ~) RING (STOP ~)	ZBR54610												
	392	PLUGS WITH ORING KIT (KIT-B)	78 5	NOZZLE (AIR ~) PLUG (FILL ~)	ZBR53660												
	523	TIE ROD KIT (HYDRAULIC ~)	522 66 92	ROD SCREW WASHER	ZBR55270	ZBR55280	ZBR55290	ZBR55300	ZBR55310	ZBR55320	ZBR55330						

PENTAIR				DRW. DR150009	SPARE-PARTS											
				Select language English	SPARE-PARTS KIT TABLE											
SPARE-PARTS				PVM 64	PUMP MODEL											
RECOMME NDED PARTS KIT	KIT REF. Nr.	KIT DESCRIPTION	COMPONE NT REF. Nr.	COMPONENT DESCRIPTION	PVM 64-1-1 F T	PVM 64-1 F T	PVM 64-2-2 F T	PVM 64-2-1 F T	PVM 64-2 F T	PVM 64-3-2 F T	PVM 64-3-1 F T	PVM 64-3 F T	PVM 64-4-2 F T	PVM 64-4-1 F T	PVM 64-4 F T	
	82	TIE ROD KIT (PUMP BODY ~)	97 214 339	NUT (TIE ROD LOCKING ~) WASHER ROD	ZBR55370	4 pc	ZBR55380	4 pc	ZBR55390	4 pc	ZBR55400	4 pc				
	453	SUPPORT FLANGE KIT	463	FLANGE		4 pc		4 pc		4 pc						
			36	RING (ELASTIC ~)												
	201	GASKET KIT	516 412 228 25	O-RING GASKET GASKET (ANTI-VIBRATION ~) O-RING (PUMP BODY ~)	ZBR54620 (EPDM standard)										1 pc	
			273	RING (STOP ~)											6 pc	
			276	RING (GUIDE ~)											4 pc	
	374	HYDRAULIC KIT WITH BEARING	277 487 21 319 73	SUPPORT (GUIDE RING ~) BEARING IMPELLER BUSHING (CONIC ~) NUT	ZBR55460 (with Standard impeller) ZBR55470 (with reduced impeller)										2 pc	
			290	CHAMBER (DIFFUSER-BEARING-RING INTERM. ~)											1 pc	
			273	RING (STOP ~)											1 pc	
	323	STAGE (INTERMEDIATE ~)KIT	276 277 21 319 73	RING (GUIDE ~) SUPPORT (GUIDE RING ~) IMPELLER BUSHING (CONIC ~) NUT	ZBR55480 (with Standard impeller) ZBR55490 (with reduced impeller)										1 pc	
			277	SUPPORT (GUIDE RING ~)											1 pc	
			21	IMPELLER											1 pc	
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR53630										1 pc	
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR49310 SUUE										1 pc	
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR49340 SQBE										1 pc	
	373	HYDRAULIC KIT, LAST STAGE	11	DIFFUSER (DISCHARGE ~)	ZBR55500										1 pc	
	372	HYDRAULIC KIT	21	IMPELLER	-	ZBR55510										1 pc
	578	HYDRAULIC KIT	577	REDUCED IMPELLER	ZBR55520	1 pc	-	ZBR55520	1 pc	-	ZBR55520	1 pc	-	ZBR55520	1 pc	
	384	PUMP BODY KIT	288	BASE (PUMP ~)	ZBR55530										1 pc	
	402	MOTOR KIT	488	COMPLETE MOTOR	ZBR47010	1 pc	ZBR50970	1 pc	ZBR50980	1 pc	ZBR50990	1 pc	ZBR51010	1 pc	ZBR47660	1 pc
	560	BOLTS AND SCREWS KIT	109 4 107 71 105	NUT (MOTOR LOCKING ~) SCREW SCREW (MOTOR LOCKING ~ / INTERNAL SUPPORT) WASHER SCREW	ZBR54650	4 pc	ZBR54660	4 pc	ZBR54670	4 pc						
						4 pc		4 pc		4 pc						
	404	SHAFT KIT	232	SHAFT	ZBR55540	1 pc	ZBR55550	1 pc	ZBR55560	1 pc	ZBR55570	1 pc				
	341	BEARING KIT	108 92 413 476 278 165 158	WASHER (TOOTHED ~) WASHER SCREW BUSHING RING (BEARING ~) WASHER (BEARING LOCK ~) SCREW (STOP ~)	ZBR53910										1 pc	
															1 pc	
															1 pc	
	405	COUPLING KIT	103	COUPLING (MOTOR PUMP ~)	ZBR53730	1 pc	ZBR53740	1 pc	ZBR53750	1 pc	ZBR53760	1 pc				
	356	MOTOR COMPLETE KIT	289 228	MOTOR (COMPLETE ~ W / IMPELLER) GASKET (ANTI-VIBRATION ~)	ZBR54640										1 pc	
															4 pc	
	406	MOTOR STOOL KIT	27 107	LANTERN SCREW (MOTOR LOCKING ~ / INTERNAL SUPPORT)	ZBR53860	1 pc	ZBR53870	1 pc	ZBR53880	1 pc						
					4 pc	4 pc	4 pc	4 pc	4 pc	4 pc						
	411	GUARD COUPLING KIT	274 414	GUARD COUPLING SCREW GUARD COUPLING	ZBR53780					4 pc	ZBR53790					
										2 pc						
	452	HYDRAULIC KIT, FIRST STAGE	21 273 276 277 319 73 284	IMPELLER RING (STOP ~) RING (GUIDE ~) SUPPORT (GUIDE RING ~) BUSHING (CONIC ~) NUT INTERCONNECTOR (COMPLETE SUCTION ~)	ZBR55620 (with Standard impeller) ZBR55630 (with reduced impeller)										1 pc	
															1 pc	
															1 pc	
	474	SLEEVE KIT	83	SLEEVE	ZBR55640	1 pc	ZBR55650	1 pc	ZBR55660	1 pc	ZBR55670	1 pc				
★	475	WEAR RINGS KIT	276 277 273	RING (GUIDE ~) SUPPORT (GUIDE RING ~) RING (STOP ~)	ZBR55720										1 pc	
															1 pc	
															1 pc	
	392	PLUGS WITH ORING KIT (KIT-B)	78 5	NOZZLE (AIR ~) PLUG (FILL ~)	ZBR53660										1 pc	
															5 pc	
	523	TIE ROD KIT (HYDRAULIC ~)	522 66 92	ROD SCREW WASHER	ZBR55730	2 pc	ZBR55740	2 pc	ZBR55750	2 pc	ZBR55760	2 pc				
					2 pc	2 pc	2 pc	2 pc	2 pc	2 pc	2 pc	2 pc				

PENTAIR				DRW. DR150009		SPARE-PARTS												
				Select language English ▼		SPARE-PARTS KIT TABLE												
SPARE-PARTS				PVM 64		PUMP MODEL												
RECOMMENDED PARTS KIT	KIT REF. Nr.	KIT DESCRIPTION	COMPONENT REF. Nr.	COMPONENT DESCRIPTION		PVM 64-5-2 F T	PVM 64-5-1 F T	PVM 64-5 F T	PVM 64-6-2 F T	PVM 64-6-1 F T	PVM 64-6 F T	PVM 64-7-2 F T	PVM 64-7-1 F T	PVM 64-7 F T	PVM 64-8-2 F T	PVM 64-8-1 F T		
	82	TIE ROD KIT (PUMP BODY ~)	97 214 339	NUT (TIE ROD LOCKING ~) WASHER ROD		ZBR55410			ZBR55420		4 pc 4 pc 4 pc	ZBR55430		4 pc 4 pc 4 pc	ZBR55440		4 pc 4 pc 4 pc	
	453	SUPPORT FLANGE KIT	463 36	FLANGE RING (ELASTIC ~)		ZBR55450												2 pc 2 pc
	201	GASKET KIT	516 412 228 25	O-RING GASKET GASKET (ANTI-VIBRATION ~) O-RING (PUMP BODY ~)		ZBR54620 (EPDM standard)												1 pc 6 pc 4 pc 2 pc
	374	HYDRAULIC KIT WITH BEARING	290 273 276 277 487 21 319 73	CHAMBER (DIFFUSER-BEARING-RING INTERM. ~) RING (STOP ~) RING (GUIDE ~) SUPPORT (GUIDE RING ~) BEARING IMPELLER BUSHING (CONIC ~) NUT		ZBR55460 (with Standard impeller) ZBR55470 (with reduced impeller)												1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc
	323	STAGE (INTERMEDIATE ~)KIT	308 273 276 277 21 319 73	CHAMBER (UPPER ~ WITH DIFFUSER) RING (STOP ~) RING (GUIDE ~) SUPPORT (GUIDE RING ~) IMPELLER BUSHING (CONIC ~) NUT		ZBR55480 (with Standard impeller) ZBR55490 (with reduced impeller)												1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)		ZBR53630												1 pc
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)		ZBR49310 SUUE												1 pc
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)		ZBR49340 SQBE												1 pc
	373	HYDRAULIC KIT, LAST STAGE	11	DIFFUSER (DISCHARGE ~)		ZBR55500												1 pc
	372	HYDRAULIC KIT	21	IMPELLER		ZBR55510												1 pc
	578	HYDRAULIC KIT	577	REDUCED IMPELLER		ZBR55520	1 pc	-	ZBR55520	1 pc	-	ZBR55520	1 pc	-	ZBR55520	1 pc		
	384	PUMP BODY KIT	288	BASE (PUMP ~)		ZBR55530												1 pc
	402	MOTOR KIT	488	COMPLETE MOTOR		ZBR51180		1 pc	ZBR55340				1 pc	ZBR55350			1 pc	
	560	BOLTS AND SCREWS KIT	109 4 107 71 105	NUT (MOTOR LOCKING ~) SCREW VITE FISSAGGIO MOTORE/SUPPORTO INT. WASHER SCREW		ZBR54670												4 pc 4 pc 4 pc 4 pc 4 pc
	404	SHAFT KIT	232	SHAFT		ZBR55580	1 pc	ZBR55590				1 pc	ZBR55600		1 pc	ZBR55610		1 pc
	341	BEARING KIT	108 92 413 476 278 165 158	WASHER (TOOTHED ~) WASHER SCREW BUSHING RING (BEARING ~) WASHER (BEARING LOCK ~) SCREW (STOP ~)		ZBR53910												1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc
	405	COUPLING KIT	103	COUPLING (MOTOR PUMP ~)		ZBR54630												1 pc
	356	MOTOR COMPLETE KIT	289 228	MOTOR (COMPLETE ~ W / IMPELLER) GASKET (ANTI-VIBRATION ~)		ZBR54640												1 pc 4 pc
	406	MOTOR STOOL KIT	27 107	LANTERN SCREW (MOTOR LOCKING ~ / INTERNAL SUPPORT)		ZBR53890		1 pc 4 pc	ZBR54680									1 pc 4 pc
	411	GUARD COUPLING KIT	274 414	GUARD COUPLING SCREW GUARD COUPLING		ZBR53790												4 pc 2 pc
	452	HYDRAULIC KIT, FIRST STAGE	21 273 276 277 319 73 284	IMPELLER RING (STOP ~) RING (GUIDE ~) SUPPORT (GUIDE RING ~) BUSHING (CONIC ~) NUT INTERCONNECTOR (COMPLETE SUCTION ~)		ZBR55620 (with Standard impeller) ZBR55630 (with reduced impeller)												1 pc 1 pc 1 pc 1 pc 1 pc 1 pc
	474	SLEEVE KIT	83	SLEEVE		ZBR55680	1 pc	ZBR55690				1 pc	ZBR55700		1 pc	ZBR55710		2
★	475	WEAR RINGS KIT	276 277 273	RING (GUIDE ~) SUPPORT (GUIDE RING ~) RING (STOP ~)		ZBR55720												1 pc 1 pc 1 pc
	392	PLUGS WITH ORING KIT (KIT-B)	78 5	NOZZLE (AIR ~) PLUG (FILL ~)		ZBR53660												1 pc 5 pc
	523	TIE ROD KIT (HYDRAULIC ~)	522 66 92	ROD SCREW WASHER		ZBR55770	2 pc 2 pc 2 pc	ZBR55780				2 pc 2 pc 2 pc	ZBR55790		2 pc 2 pc 2 pc	ZBR55800		2 pc 2 pc 2 pc

PENTAIR				DRW. DR150009		SPARE-PARTS												
				Select language English		SPARE-PARTS KIT TABLE												
SPARE-PARTS				PVM 90		PUMP MODEL												
RECOMMENDED PARTS KIT	KIT REF. Nr.	KIT DESCRIPTION	COMPONENT REF. Nr.	COMPONENT DESCRIPTION	PVM 90-1-1 F T	PVM 90-1 F T	PVM 90-2-2 F T	PVM 90-2 F T	PVM 90-3-2 F T	PVM 90-3 F T	PVM 90-4-2 F T	PVM 90-4 F T	PVM 90-5-2 F T	PVM 90-5 F T	PVM 90-6-2 F T	PVM 90-6 F T		
	82	TIE ROD KIT (PUMP BODY ~)	97 214 339	NUT (TIE ROD LOCKING ~) WASHER ROD	ZBR55820	4 pc	ZBR55830	4 pc	ZBR55840	4 pc	ZBR55850	4 pc	ZBR55860	4 pc	ZBR55870	4 pc		
	453	SUPPORT FLANGE KIT	463 36	FLANGE RING (ELASTIC ~)	ZBR55450											2 pc		
	201	GASKET KIT	516 412 228 25	O-RING GASKET GASKET (ANTI-VIBRATION ~) O-RING (PUMP BODY ~)	ZBR55900 (EPDM standard)											1 pc 6 pc 4 pc 2 pc		
	374	HYDRAULIC KIT WITH BEARING	290 273 276 277 487 21 319 73	CHAMBER (DIFFUSER-BEARING-RING INTERM. ~) RING (STOP ~) RING (GUIDE ~) SUPPORT (GUIDE RING ~) BEARING IMPELLER BUSHING (CONIC ~) NUT	ZBR55880 (with Standard impeller) ZBR55890 (with reduced impeller)											1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc		
	323	STAGE (INTERMEDIATE ~)KIT	308 273 276 277 21 319 73	CHAMBER (UPPER ~ WITH DIFFUSER) RING (STOP ~) RING (GUIDE ~) SUPPORT (GUIDE RING ~) IMPELLER BUSHING (CONIC ~) NUT	ZBR55910 (with Standard impeller) ZBR55920 (with reduced impeller)											1 pc 1 pc 1 pc 1 pc 1 pc 1 pc		
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR53630											1 pc		
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR49310 SUUE											1 pc		
	371	MECHANICAL SEAL KIT	24	SEAL (COMPLETE MECHANICAL ~)	ZBR49340 SQBE											1 pc		
	373	HYDRAULIC KIT, LAST STAGE	11	DIFFUSER (DISCHARGE ~)	ZBR55930											1 pc		
	372	HYDRAULIC KIT	21	IMPELLER	-	ZBR55940	1 pc	-	ZBR55940								1 pc	
	578	HYDRAULIC KIT	577	REDUCED IMPELLER	ZBR55950	1 pc	-	ZBR55950	1 pc	-	ZBR55950	1 pc	-	ZBR55950	1 pc	-	ZBR55950	1 pc
	384	PUMP BODY KIT	288	BASE (PUMP ~)	ZBR55960												1 pc	
	402	MOTOR KIT	488	COMPLETE MOTOR	ZBR50970	1 pc	ZBR50980	1 pc	ZBR50990	1 pc	ZBR51010	1 pc	ZBR47660	1 pc	ZBR51000	1 pc	ZBR51180	1 pc
	560	BOLTS AND SCREWS KIT	109 4 107 71 105	NUT (MOTOR LOCKING ~) SCREW SCREW (MOTOR LOCKING ~ / INTERNAL SUPPORT) WASHER SCREW	ZBR53830	4 pc	ZBR53840										4 pc 4 pc 4 pc 4 pc	
	404	SHAFT KIT	232	SHAFT	ZBR55970	1 pc	ZBR55980	1 pc	ZBR55990	1 pc	ZBR56000	1 pc	ZBR56010	1 pc	ZBR56020	1 pc		
	341	BEARING KIT	108 92 413 476 278 165 158	WASHER (TOOTHED ~) WASHER SCREW BUSHING RING (BEARING ~) WASHER (BEARING LOCK ~) SCREW (STOP ~)	ZBR53910											1 pc 1 pc 1 pc 1 pc 1 pc 1 pc		
	405	COUPLING KIT	103	COUPLING (MOTOR PUMP ~)	ZBR53740	1 pc	ZBR53750	1 pc	ZBR53760	1 pc	ZBR54630						1 pc	
	356	MOTOR COMPLETE KIT	289 228	MOTOR (COMPLETE ~ W / IMPELLER) GASKET (ANTI-VIBRATION ~)	ZBR56030											1 pc 4 pc		
	406	MOTOR STOOL KIT	27 107	LANTERN SCREW (MOTOR LOCKING ~ / INTERNAL SUPPORT)	ZBR53870	1 pc	ZBR53880	1 pc	ZBR53890	1 pc	ZBR54680						1 pc 4 pc	
	411	GUARD COUPLING KIT	274 414	GUARD COUPLING SCREW GUARD COUPLING	ZBR53780	4 pc 2 pc	ZBR53790										4 pc 2 pc	
	452	HYDRAULIC KIT, FIRST STAGE	21 273 276 277 319 73 284	IMPELLER RING (STOP ~) RING (GUIDE ~) SUPPORT (GUIDE RING ~) BUSHING (CONIC ~) NUT INTERCONNECTOR (COMPLETE SUCTION ~)	ZBR56040 (with Standard impeller) ZBR56050 (with reduced impeller)											1 pc 1 pc 1 pc 1 pc 1 pc 1 pc		
	474	SLEEVE KIT	83	SLEEVE	ZBR56060	1 pc	ZBR56070	1 pc	ZBR56080	1 pc	ZBR56090	1 pc	ZBR56100	1 pc	ZBR56110	1 pc		
★	475	WEAR RINGS KIT	276 277 273	RING (GUIDE ~) SUPPORT (GUIDE RING ~) RING (STOP ~)	ZBR56120											1 pc 1 pc 1 pc		
	392	PLUGS WITH ORING KIT (KIT-B)	78 5	NOZZLE (AIR ~) PLUG (FILL ~)	ZBR53660											1 pc 5 pc		
	523	TIE ROD KIT (HYDRAULIC ~)	522 66 92	ROD SCREW WASHER	ZBR56130	2 pc 2 pc 2 pc	ZBR56140	2 pc 2 pc 2 pc	ZBR56150	2 pc 2 pc 2 pc	ZBR56160	2 pc 2 pc 2 pc	ZBR56170	2 pc 2 pc 2 pc	ZBR56180	2 pc 2 pc 2 pc		