

				DRW. DR090004	SPARE-PARTS										
				Select language English	SPARE-PARTS KIT TABLE										
SPARE-PARTS				VLR2	PUMP MODEL										
RECOMMENDED PARTS KIT	KIT REF. Nr.	KIT DESCRIPTION	COMPONENT REF. Nr.	COMPONENT DESCRIPTION	VLR 2B-30/2A M	VLR 2B-30/2A T	VLR 2B-30A M	VLR 2B-30A T	VLR 2B-40A M	VLR 2B-40A T	VLR 2B-50A M	VLR 2B-50A T	VLR 2B-60A M	VLR 2B-60A T	
	82	TIE ROD KIT (PUMP BODY ~)	97	NUT (TIE ROD LOCKING ~)	ZBR30060			4 pcs	ZBR30070	4 pcs	ZBR30080	4 pcs	ZBR30090	4 pcs	
			214	WASHER				4 pcs				4 pcs			
			339	ROD				4 pcs				4 pcs			
			4	SCREW								4 pcs			
	200	BOLTS AND SCREWS KIT	66	SCREW	ZBR30450									4 pcs	
			105	SCREW										4 pcs	
			273	RING (STOP ~)										1 pcs	
			274	GUARD COUPLING SCREW										4 pcs	
	201	GASKET KIT	5	PLUG (FILL ~)	ZBR30380									1 pcs	
			25	O-RING (PUMP BODY ~)										2 pcs	
			78	NOZZLE (AIR ~)										1 pcs	
			87	O-RING (SHUTTER ~)										1 pcs	
			412	GASKET										2 pcs	
	323	STAGE (INTERMEDIATE ~)KIT	9	DIFFUSER	-									1 pcs	
			21	IMPELLER										1 pcs	
			276	RING (GUIDE ~)										1 pcs	
			277	SUPPORT (GUIDE RING ~)										1 pcs	
			478	SPACER										1 pcs	
	371	MECHANICAL SEAL KIT	266	SEAL (STATIONARY ~)	ZBR22300									1 pcs	
			267	SEAL (ROTATING ~)										1 pcs	
			482	ADJUSTMENT SPACER										1 pcs	
			9	DIFFUSER										1 pcs	
	373	HYDRAULIC KIT, LAST STAGE	21	IMPELLER	ZBR30440									1 pcs	
			276	RING (GUIDE ~)										1 pcs	
			277	SUPPORT (GUIDE RING ~)										1 pcs	
			477	SPACER										1 pcs	
			485	SPACER										1 pcs	
	374	HYDRAULIC KIT WITH BEARING	9	DIFFUSER	ZBR30390									1 pcs	
			21	IMPELLER										1 pcs	
			276	RING (GUIDE ~)										1 pcs	
			277	SUPPORT (GUIDE RING ~)										1 pcs	
			479	SPACER										1 pcs	
			487	BEARING										1 pcs	
	384	PUMP BODY KIT	288	BASE (PUMP ~)	ZBR30040										1 pcs
	402	MOTOR KIT	488	COMPLETE MOTOR	ZBR21130	ZBR21140	ZBR21130	ZBR21140	ZBR21150	ZBR21160	ZBR21150	ZBR21160	ZBR21210	ZBR21220	1 pcs
			71	WASHER				1 pcs				1 pcs			1 pcs
	404	SHAFT KIT	73	NUT	ZBR30220			1 pcs	ZBR30240			1 pcs	ZBR30250	ZBR30260	1 pcs
			166	WASHER (SEAL COMPRESSION ~)				1 pcs				1 pcs			
			232	SHAFT				1 pcs				1 pcs			
			103	COUPLING (MOTOR PUMP ~)								1 pcs			
	405	COUPLING KIT	237	SCREW (COUPLING ~)				ZBR30000					ZBR30010		2 pcs
															4 pcs
	406	LANTERN KIT	27	LANTERN				ZBR30180				1 pcs	ZBR30190		1 pcs
	411	GUARD COUPLING KIT	274	GUARD COUPLING SCREW	ZBR30350										2 pcs
			414	GUARD COUPLING											2 pcs
	452	HYDRAULIC KIT, FIRST STAGE	9	DIFFUSER	ZBR30410										1 pcs
			21	IMPELLER											1 pcs
			276	RING (GUIDE ~)											1 pcs
			277	SUPPORT (GUIDE RING ~)											1 pcs
			435	SPACER											1 pcs
	458	DIFFUSER KIT	9	DIFFUSER	ZBR30400			1 pcs	-						
			276	RING (GUIDE ~)				1 pcs							
			277	SUPPORT (GUIDE RING ~)				1 pcs							
			477	SPACER				1 pcs							
			485	SPACER			1 pcs								
	474	SLEEVE KIT	25	O-RING (PUMP BODY ~)	ZBR30460				2 pcs			2 pcs		2 pcs	2 pcs
			83	SLEEVE					1 pcs			1 pcs		1 pcs	1 pcs
*	475	WEAR RINGS KIT	276	RING (GUIDE ~)	ZBR30520										1 pcs
			277	SUPPORT (GUIDE RING ~)											1 pcs
	483	CHAMBER (UPPER ~ WITH DIFFUSER)KIT	11	DIFFUSER (DISCHARGE ~)	ZBR30430										1 pcs
			36	RING (ELASTIC ~)											1 pcs
			87	O-RING (SHUTTER ~)	ZBR30370										1 pcs
	484	RECYCLING PLUG KIT	88	SHUTTER											1 pcs
			412	GASKET											1 pcs
			476	BUSHING											1 pcs

Ricambi validi per i modelli con codice E1Axxxxx/E1Dxxxxx, per i modelli dove in etichetta non è presente alcun codice prodotto contattare il ns. ufficio Post-Vendita
Spare parts valid for models E1Axxxxx/E1Dxxxxx. For models which is not indicated Part number, please contact our After Sales
Pièces détachées valables pour les modèles E1Axxxxx/E1Dxxxxx. Pour les modèles pour lesquels il n'y pas d'indication, veuillez contacter notre Service Après Vente
Ersatzteile gültig für Modelle mit Artikel Nummer E1Axxxxx/E1Dxxxxx Für Modelle, die kein Artikel Nummer, bitte nehmen Sie Kontakt mit unser Service Büro

				DRW. DR090004	SPARE-PARTS											
				Select language English	SPARE-PARTS KIT TABLE											
SPARE-PARTS				VLR4	PUMP MODEL											
RECOMMENDED PARTS KIT	KIT REF. N°.	KIT DESCRIPTION	COMPONENT REF. N°.	COMPONENT DESCRIPTION	VLR 4-20A M	VLR 4-20A T	VLR 4-30A M	VLR 4-30A T	VLR 4-40A M	VLR 4-40A T	VLR 4-50A M	VLR 4-50A T	VLR 4-60A M	VLR 4-60A T	VLR 4-80/7A M	VLR 4-80/7A T
	82	TIE ROD KIT (PUMP BODY -)	97 214 339 4 66 105 273 274	NUT (TIE ROD LOCKING -) WASHER ROD SCREW SCREW SCREW RING (STOP -) GUARD COUPLING SCREW	ZBR30060		ZBR30590		ZBR30090		ZBR30600		ZBR30110		ZBR30610	
	200	BOLTS AND SCREWS KIT	5 25 78 87 412	PLUG (FILL -) O-RING (PUMP BODY -) NOZZLE (AIR -) O-RING (SHUTTER -) GASKET												
	201	GASKET KIT	9 21 276 277 476	DIFFUSER IMPELLER RING (GUIDE -) SUPPORT (GUIDE RING -) SPACER												
	323	STAGE (INTERMEDIATE -)KIT	276 277 476	RING (GUIDE -) SUPPORT (GUIDE RING -) SPACER												
	371	MECHANICAL SEAL KIT	256 267 482	SEAL (STATIONARY -) SEAL (ROTATING -) ADJUSTMENT SPACER												
	373	HYDRAULIC KIT, LAST STAGE	9 21 276 277 477 485	DIFFUSER IMPELLER RING (GUIDE -) SUPPORT (GUIDE RING -) SPACER SPACER												
	374	HYDRAULIC KIT WITH BEARING	9 21 276 277 479 487	DIFFUSER IMPELLER RING (GUIDE -) SUPPORT (GUIDE RING -) SPACER BEARING												
	384	PUMP BODY KIT	288	BASE (PUMP -)												
	402	MOTOR KIT	488	COMPLETE MOTOR	ZBR21130	ZBR21140	ZBR21150	ZBR21160	ZBR21210	ZBR21220	ZBR30710	ZBR21230	ZBR30710	ZBR21230	ZBR30720	ZBR21300
	404	SHAFT KIT	71 73 166 232	WASHER NUT WASHER (SEAL COMPRESSION -) SHAFT	ZBR30220		ZBR30230		ZBR30260		ZBR30870		ZBR30280		ZBR30890	
	405	COUPLING KIT	103 237	COUPLING (MOTOR PUMP -) SCREW (COUPLING -)		ZBR30000			ZBR30010		ZBR30020	ZBR30010	ZBR30020	ZBR30010	ZBR30020	
	406	LANTERN KIT	27	LANTERN		ZBR30180			ZBR30190		ZBR30200	ZBR30190	ZBR30200	ZBR30190	ZBR30200	
	411	GUARD COUPLING KIT	274 434	GUARD COUPLING SCREW GUARD COUPLING			ZBR30350				ZBR30360	ZBR30350	ZBR30360	ZBR30350	ZBR30360	
	452	HYDRAULIC KIT, FIRST STAGE	9 21 435 276 277	DIFFUSER IMPELLER SPACER RING (GUIDE -) SUPPORT (GUIDE RING -)												
	458	DIFFUSER KIT	9 276 277 477 485	DIFFUSER RING (GUIDE -) SUPPORT (GUIDE RING -) SPACER SPACER											ZBR30990	
	474	SLEEVE KIT	25 83	O-RING (PUMP BODY -) SLEEVE	ZBR30460		ZBR31020		ZBR30490		ZBR31030		ZBR30510		ZBR31040	
*	475	WEAR RINGS KIT	276 277	RING (GUIDE -) SUPPORT (GUIDE RING -)												
	483	CHAMBER (UPPER - WITH DIFFUSER)KIT	11 36	DIFFUSER (DISCHARGE -) RING (ELASTIC -)												
	484	RECYCLING PLUG KIT	87 88 412 476	O-RING (SHUTTER -) SHUTTER GASKET BUSHING												
	498	HYDRAULIC KIT WITH BEARING AND SPACER	9 21 276 277 477 479 487	DIFFUSER IMPELLER RING (GUIDE -) SUPPORT (GUIDE RING -) SPACER SPACER BEARING	ZBR30820											

Ricambi validi per i modelli con codice E2Axxxxx /E2Dxxxxx, per i modelli dove in etichetta non è presente alcun codice prodotto contattare il ns. ufficio Post-Vendita
 Spare parts valid for models E2Axxxxx/E2Dxxxxx. For models which in label is not indicated Part number, please contact our After Sales
 Pièces détachées valables pour les modèles E2Axxxxx/E2Dxxxxx. Pour les modèles pour lesquels il n'y pas d'indication, veuillez contacter notre Service Après Vente
 Ersatzteile gültig für Modelle mit Artikel Nummer E2Axxxxx /E2Dxxxxx Für Modelle, die kein Artikel Nummer, bitte nehmen Sie Kontakt mit unser Service Büro

				DRW. DR090004	SPARE-PARTS									
				Select language English	SPARE-PARTS KIT TABLE									
SPARE-PARTS				VLR4	PUMP MODEL									
RECOMMENDED PARTS KIT	KIT REF. Nr.	KIT DESCRIPTION	COMPONENT REF. Nr.	COMPONENT DESCRIPTION	VLR 4-80A M	VLR 4-80A T	VLR 4-100A T	VLR 4-120A T	VLR 4-140A T	VLR 4-160A T	VLR 4-190F T	VLR 4-220F T	VLR 4-240F T	VLR 4-260F T
82	TIE ROD KIT (PUMP BODY ~)		97	NUT (TIE ROD LOCKING ~)	ZBR30610		ZBR30140	ZBR30150	ZBR30620	ZBR30630	ZBR30640	ZBR30650	ZBR30660	ZBR30670
			214	WASHER										
			339	ROD										
200	BOLTS AND SCREWS KIT		4	SCREW	ZBR30680									
			66	SCREW										
			105	SCREW										
			273	RING (STOP ~)										
			274	GUARD COUPLING SCREW										
			5	PLUG (FILL ~)										
201	GASKET KIT		25	O-RING (PUMP BODY ~)	ZBR30380									
			78	NOZZLE (AIR ~)										
			87	O-RING (SHUTTER ~)										
			412	GASKET										
			9	DIFFUSER										
323	STAGE (INTERMEDIATE ~)KIT		21	IMPELLER	ZBR30810									
			276	RING (GUIDE ~)										
			277	SUPPORT (GUIDE RING ~)										
			478	SPACER										
			266	SEAL (STATIONARY ~)										
371	MECHANICAL SEAL KIT		267	SEAL (ROTATING ~)	ZBR22300									
			482	ADJUSTMENT SPACER										
			9	DIFFUSER										
373	HYDRAULIC KIT, LAST STAGE		21	IMPELLER	ZBR30790									
			276	RING (GUIDE ~)										
			277	SUPPORT (GUIDE RING ~)										
			477	SPACER										
			485	SPACER										
			9	DIFFUSER										
374	HYDRAULIC KIT WITH BEARING		21	IMPELLER	ZBR30830									
			276	RING (GUIDE ~)										
			277	SUPPORT (GUIDE RING ~)										
			479	SPACER										
			487	BEARING										
			288	BASE (PUMP ~)										
384	PUMP BODY KIT		488	COMPLETE MOTOR	ZBR30720	ZBR21300	ZBR30730	ZBR30730	ZBR21250	ZBR26630	ZBR30050	ZBR31110		
404	SHAFT KIT		71	WASHER	ZBR30890		ZBR30310	ZBR30320	ZBR30920	ZBR30930	ZBR30940	ZBR30950	ZBR30960	ZBR30970
			73	NUT										
			166	WASHER (SEAL COMPRESSION ~)										
			232	SHAFT										
405	COUPLING KIT		103	COUPLING (MOTOR PUMP ~)	ZBR30020					ZBR30030			ZBR30780	
			237	SCREW (COUPLING ~)										
406	LANTERN KIT		27	LANTERN	ZBR30200					ZBR30210			ZBR31000	
411	GUARD COUPLING KIT		274	GUARD COUPLING SCREW	ZBR30360									
			414	GUARD COUPLING										
452	HYDRAULIC KIT, FIRST STAGE		9	DIFFUSER	ZBR30980									
			21	IMPELLER										
			435	SPACER										
			276	RING (GUIDE ~)										
			277	SUPPORT (GUIDE RING ~)										
474	SLEEVE KIT		25	O-RING (PUMP BODY ~)	ZBR31040		ZBR30550	ZBR30560	ZBR31050	ZBR31060	ZBR31070	ZBR31080	ZBR31090	ZBR31100
			83	SLEEVE										
★	WEAR RINGS KIT		276	RING (GUIDE ~)	ZBR31010									
			277	SUPPORT (GUIDE RING ~)										
483	CHAMBER (UPPER ~ WITH DIFFUSER)KIT		11	DIFFUSER (DISCHARGE ~)	ZBR30800									
			36	RING (ELASTIC ~)										
484	RECYCLING PLUG KIT		87	O-RING (SHUTTER ~)	ZBR30370									
			88	SHUTTER										
			412	GASKET										
			476	BUSHING										

Ricambi validi per i modelli con codice E2Axxxxx /E2Dxxxxx, per i modelli dove in etichetta non è presente alcun codice prodotto contattare il ns. ufficio Post-Vendita
 Spare parts valid for models E2Axxxxx/E2Dxxxxx. For models which in label is not indicated Part number, please contact our After Sales
 Pièces détachées valables pour les modèles E2Axxxxx/E2Dxxxxx. Pour les modèles pour lesquels il n'y pas d'indication, veuillez contacter notre Service Après Vente
 Ersatzteile gültig für Modelle mit Artikel Nummer E2Axxxxx /E2Dxxxxx Für Modelle, die kein Artikel Nummer, bitte nehmen Sie Kontakt mit unser Service Büro

				DRW. DR090006	SPARE-PARTS																																							
				Select language English	SPARE-PARTS KIT TABLE																																							
SPARE-PARTS				VLR8	PUMP MODEL																																							
RECOMMEN DED PARTS KIT	KIT REF. Nr.	-	COMPONENT REF. Nr.	COMPONENT DESCRIPTION	VLR 8-20A M	VLR 8-20A T	VLR 8-30A M	VLR 8-30A T	VLR 8-40A M	VLR 8-40A T	VLR 8-50A T	VLR 8-60A T	VLR 8-80A T	VLR 8-100 A T	VLR 8-120 A T	VLR 8-140F T	VLR 8-160F T	VLR 8-180F T	VLR 8-200F T																									
	82	TIE ROD KIT (PUMP BODY ~)	339 214 97	ROD WASHER NUT (TIE ROD LOCKING ~)	ZBR32760	4 pc 4 pc 4 pc	ZBR32770	4 pc 4 pc 4 pc	ZBR32780	4 pc 4 pc 4 pc	ZBR32790	4 pc 4 pc 4 pc	ZBR32800	4 pc 4 pc 4 pc	ZBR32810	4 pc 4 pc 4 pc	ZBR32820	4 pc 4 pc 4 pc	ZBR32830	4 pc 4 pc 4 pc	ZBR32840	4 pc 4 pc 4 pc	ZBR32850	4 pc 4 pc 4 pc	ZBR32860	4 pc 4 pc 4 pc	ZBR32870	4 pc 4 pc 4 pc																
	200	BOLTS AND SCREWS KIT	66 274 237 105 273 4 417	SCREW GUARD COUPLING SCREW SCREW (COUPLING ~) SCREW RING (STOP ~) SCREW PIN	ZBR32880															2 pc 2 pc 4 pc 4 pc 1 pc 4 pc																								
	201	GASKET KIT	5 78 6 87 25 333	PLUG (FILL ~) NOZZLE (AIR ~) GASKET (FILL/DRAIN PLUG ~) O-RING (SHUTTER ~) O-RING (PUMP BODY ~) PLUG (SIDE ~)	ZBR32890															2 pc 1 pc 1 pc 1 pc 2 pc 1 pc																								
★	371	MECHANICAL SEAL KIT	67 482 266 267	WASHER ADJUSTMENT SPACER SEAL (STATIONARY ~) SEAL (ROTATING ~)	ZBR22310															0 pc 1 pc 1 pc 1 pc																								
	323	STAGE (INTERMEDIATE ~)KIT	21 478 277 276 9	IMPELLER SPACER SUPPORT (GUIDE RING ~) RING (GUIDE ~) DIFFUSER	ZBR33120															1 pc 1 pc 1 pc 1 pc 1 pc																								
	373	HYDRAULIC KIT, LAST STAGE	21 477 478 277 276 9	IMPELLER SPACER SPACER SUPPORT (GUIDE RING ~) RING (GUIDE ~) DIFFUSER	ZBR32900															1 pc 1 pc 1 pc 1 pc 1 pc 1 pc																								
	374	HYDRAULIC KIT WITH BEARING	21 479 276 277 487 290	IMPELLER SPACER RING (GUIDE ~) SUPPORT (GUIDE RING ~) BEARING CHAMBER (DIFFUSER-BEARING-RING INTERM. ~)	ZBR33130															1 pc 1 pc 1 pc 1 pc 1 pc 1 pc																								
	384	PUMP BODY KIT	288	BASE (PUMP ~)	ZBR33140															1 pc																								
	402	MOTOR KIT	488	COMPLETE MOTOR	ZBR21210	1 pc	ZBR21220	1 pc	ZBR30710	1 pc	ZBR21230	1 pc	ZBR30720	1 pc	ZBR21300	1 pc	ZBR30730	1 pc	ZBR21250	1 pc	ZBR26630	1 pc	ZBR31110		1 pc	ZBR33530		1 pc																
	404	SHAFT KIT	232 166 71 73	SHAFT WASHER (SEAL COMPRESSION ~) WASHER NUT	ZBR33160	1 pc 1 pc 1 pc 1 pc	ZBR33170	1 pc 1 pc 1 pc 1 pc	ZBR33180	1 pc 1 pc 1 pc 1 pc	ZBR33190	1 pc 1 pc 1 pc 1 pc	ZBR33200	1 pc 1 pc 1 pc 1 pc	ZBR33210	1 pc 1 pc 1 pc 1 pc	ZBR33220	1 pc 1 pc 1 pc 1 pc	ZBR33230	1 pc 1 pc 1 pc 1 pc	ZBR33240	1 pc 1 pc 1 pc 1 pc	ZBR33250	1 pc 1 pc 1 pc 1 pc	ZBR33260	1 pc 1 pc 1 pc 1 pc	ZBR33270	1 pc 1 pc 1 pc 1 pc																
	405	COUPLING KIT	275 237 103	PIN (MOTOR COUPLING ~) SCREW (COUPLING ~) COUPLING (MOTOR PUMP ~)	ZBR33280	1 pc 4 pc 1 pc	ZBR33290	1 pc 4 pc 1 pc	ZBR33280	1 pc 4 pc 1 pc	ZBR33290	1 pc 4 pc 1 pc	ZBR33300	1 pc 4 pc 1 pc	ZBR33310	1 pc 4 pc 1 pc	ZBR33320	1 pc 4 pc 1 pc	ZBR33330	1 pc 4 pc 1 pc	ZBR33340	1 pc 4 pc 1 pc	ZBR33350	1 pc 4 pc 1 pc	ZBR33360	1 pc 4 pc 1 pc	ZBR33370	1 pc 4 pc 1 pc																
	406	LANTERN KIT	27	LANTERN	ZBR33320	1 pc	ZBR33330	1 pc	ZBR33320	1 pc	ZBR33330	1 pc	ZBR33340	1 pc	ZBR33350	1 pc	ZBR33360	1 pc	ZBR33370	1 pc	ZBR33380	1 pc	ZBR33390	1 pc	ZBR33400	1 pc	ZBR33410	1 pc	ZBR33420	1 pc	ZBR33430	1 pc	ZBR33440	1 pc	ZBR33450	1 pc	ZBR33460	1 pc	ZBR33470	1 pc	ZBR33480	1 pc	ZBR33490	1 pc
	411	GUARD COUPLING KIT	274 414	GUARD COUPLING SCREW GUARD COUPLING	ZBR30350	2 pc 2 pc	ZBR30360	1 pc 1 pc	ZBR30350	2 pc 2 pc	ZBR30360	1 pc 1 pc	ZBR30350	2 pc 2 pc	ZBR30360	1 pc 1 pc	ZBR30350	2 pc 2 pc	ZBR30360	1 pc 1 pc	ZBR30350	2 pc 2 pc	ZBR30360	1 pc 1 pc	ZBR30350	2 pc 2 pc	ZBR30360	1 pc 1 pc	ZBR30350	2 pc 2 pc														
	452	HYDRAULIC KIT, FIRST STAGE	284 21 435 276 277 417	INTERCONNECTOR (COMPLETE SUCTION ~) IMPELLER SPACER RING (GUIDE ~) SUPPORT (GUIDE RING ~) PIN	ZBR33370															1 pc 1 pc 1 pc 1 pc 1 pc 1 pc																								
	474	SLEEVE KIT	25 83	O-RING (PUMP BODY ~) SLEEVE	ZBR33380	2 pc 1 pc	ZBR33390	2 pc 1 pc	ZBR33400	2 pc 1 pc	ZBR33410	2 pc 1 pc	ZBR33420	2 pc 1 pc	ZBR33430	2 pc 1 pc	ZBR33440	2 pc 1 pc	ZBR33450	2 pc 1 pc	ZBR33460	2 pc 1 pc	ZBR33470	2 pc 1 pc	ZBR33480	2 pc 1 pc	ZBR33490	2 pc 1 pc																
★	475	WEAR RINGS KIT	276 277	RING (GUIDE ~) SUPPORT (GUIDE RING ~)	ZBR33500															1 pc 1 pc																								
	483	CHAMBER (UPPER ~ WITH DIFFUSER)KIT	486 308	CONICAL SPRING CHAMBER (UPPER ~ WITH DIFFUSER)	ZBR33510															1 pc 1 pc																								
	484	RECYCLING PLUG KIT	6 86 87 476	GASKET (FILL/DRAIN PLUG ~) PLUG (RECYCLING ~) O-RING (SHUTTER ~) BUSHING	ZBR33520															1 pc 1 pc 1 pc 1 pc																								
	498	HYDRAULIC KIT WITH BEARING AND SPACER	21 479 276 277 477 487 290	IMPELLER SPACER RING (GUIDE ~) SUPPORT (GUIDE RING ~) SPACER BEARING CHAMBER (DIFFUSER-BEARING-RING INTERM. ~)	ZBR33540	1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc	ZBR33540	1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc	ZBR33540	1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc	ZBR33540	1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc	ZBR33540	1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc	ZBR33540	1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc	ZBR33540	1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc	ZBR33540	1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc	ZBR33540	1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc	ZBR33540	1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc	ZBR33540	1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc	ZBR33540	1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc																

Ricambi validi per i modelli con codice E3Axxxxx /E3Dxxxxx, per i modelli dove in etichetta non è presente alcun codice prodotto contattare il ns. ufficio Post-Vendita
Spare parts valid for models E3Axxxxx/E3Dxxxxx. For models which is not indicated Part number, please contact our After Sales
Pièces détachées valables pour les modèles E3Axxxxx/E3Dxxxxx. Pour les modèles pour lesquels il n'y pas d'indication, veuillez contacter notre Service Après Vente
Ersatzteile gültig für Modelle mit Artikel Nummer E3Axxxxx /E3Dxxxxx Für Modelle, die kein Artikel Nummer, bitte nehmen Sie Kontakt mit unser Service Büro

				DRW. DR090006		SPARE-PARTS									
				Select language English ▼		SPARE-PARTS KIT TABLE									
SPARE-PARTS				VLR16		PUMP MODEL									
RECOMMEN DED PARTS KIT	KIT REF. Nr.	KIT DESCRIPTION	COMPONENT REF. Nr.	COMPONENT DESCRIPTION	VLR16–20 F T	VLR 16–30 F T	VLR16–40 F T	VLR 16–50 F T	VLR 16–60 F T	VLR 16–70 F T	VLR 16–80 F T	VLR 16–100 F T	VLR 16–120 F T	VLR 16–140F T	VLR 16–160F T
	82	TIE ROD KIT (PUMP BODY ~)	339 214 97	ROD WASHER NUT (TIE ROD LOCKING ~)	ZBR33910 4 pc 4 pc 4 pc	ZBR32780 4 pc 4 pc 4 pc	ZBR33930 4 pc 4 pc 4 pc	ZBR33940 4 pc 4 pc 4 pc	ZBR33950 4 pc 4 pc 4 pc	ZBR32820 4 pc 4 pc 4 pc	ZBR33960 4 pc 4 pc 4 pc	ZBR33970 4 pc 4 pc 4 pc	ZBR33980 4 pc 4 pc 4 pc	ZBR33990 4 pc 4 pc 4 pc	ZBR34000 4 pc 4 pc 4 pc
	200	BOLTS AND SCREWS KIT	66 274 237 105 273 4 417	SCREW GUARD COUPLING SCREW SCREW (COUPLING ~) SCREW RING (STOP ~) SCREW PIN	ZBR32880										2 pc 2 pc 4 pc 4 pc 1 pc 4pc 1 pc
	201	GASKET KIT	5 78 6 87 25 333	PLUG (FILL ~) NOZZLE (AIR ~) GASKET (FILL/DRAIN PLUG ~) O-RING (SHUTTER ~) O-RING (PUMP BODY ~) PLUG (SIDE ~)	ZBR32890										2 pc 1 pc 1 pc 1 pc 2 pc 1 pc
★	371	MECHANICAL SEAL KIT	67 482 266 267	WASHER ADJUSTMENT SPACER SEAL (STATIONARY ~) SEAL (ROTATING ~)	ZBR22310										1 pc 1 pc 1 pc 1 pc
	323	STAGE (INTERMEDIATE ~)KIT	21 478 277 276 9	IMPELLER SPACER SUPPORT (GUIDE RING ~) RING (GUIDE ~) DIFFUSER	ZBR34010										1 pc 1 pc 1 pc 1 pc 1 pc
	374	HYDRAULIC KIT WITH BEARING	21 479 276 277 487 290	IMPELLER SPACER RING (GUIDE ~) SUPPORT (GUIDE RING ~) BEARING HAMBER (DIFFUSER-BEARING-RING INTERM.	ZBR36300										1 pc 1 pc 1 pc 1 pc 1 pc 1 pc
	384	PUMP BODY KIT	288	BASE (PUMP ~)	ZBR34020										1 pc
	402	MOTOR KIT	488	COMPLETE MOTOR	ZBR30730 1 pc	ZBR47910 1 pc	ZBR47920 1 pc	ZBR31110 1 pc	ZBR33530 1 pc	ZBR34030 1 pc	ZBR34040 1 pc				
	404	KIT ALBERO	232 166 71 73	SHAFT WASHER (SEAL COMPRESSION ~) WASHER NUT	ZBR34050 1 pc 1 pc 1 pc 1 pc	ZBR34060 1 pc 1 pc 1 pc 1 pc	ZBR34070 1 pc 1 pc 1 pc 1 pc	ZBR34080 1 pc 1 pc 1 pc 1 pc	ZBR34090 1 pc 1 pc 1 pc 1 pc	ZBR34100 1 pc 1 pc 1 pc 1 pc	ZBR34110 1 pc 1 pc 1 pc 1 pc	ZBR34120 1 pc 1 pc 1 pc 1 pc	ZBR34130 1 pc 1 pc 1 pc 1 pc	ZBR34140 1 pc 1 pc 1 pc 1 pc	ZBR34150 1 pc 1 pc 1 pc 1 pc
	405	COUPLING KIT	275 237 103	PIN (MOTOR COUPLING ~) SCREW (COUPLING ~) COUPLING (MOTOR PUMP ~)	ZBR33290 1 pc 4 pc 1 pc	ZBR33300 1 pc 4 pc 1 pc	ZBR33310 1 pc 4 pc 1 pc	ZBR34160 1 pc 4 pc 1 pc							
	406	LANTERN KIT	27	LANTERN	ZBR33330 1 pc	ZBR47900 1 pc	ZBR33350 1 pc	ZBR34170 1 pc							
	411	GUARD COUPLING KIT	274 414	GUARD COUPLING SCREW GUARD COUPLING	ZBR30360 2 pc 2 pc	ZBR33360 4 pc 2 pc									
	452	HYDRAULIC KIT, FIRST STAGE	284 21 435 276 277 417	INTERCONNECTOR (COMPLETE SUCTION ~) IMPELLER SPACER RING (GUIDE ~) SUPPORT (GUIDE RING ~) PIN	ZBR34180										1 pc 1 pc 1 pc 1 pc 1 pc 1 pc
	474	SLEEVE KIT	25 83	O-RING (PUMP BODY ~) SLEEVE	ZBR34190 2 pc 1 pc	ZBR33400 2 pc 1 pc	ZBR34210 2 pc 1 pc	ZBR34220 2 pc 1 pc	ZBR34230 2 pc 1 pc	ZBR33440 2 pc 1 pc	ZBR34240 2 pc 1 pc	ZBR34250 2 pc 1 pc	ZBR34260 2 pc 1 pc	ZBR34270 2 pc 1 pc	ZBR34280 2 pc 1 pc
★	475	WEAR RINGS KIT	276 277	RING (GUIDE ~) SUPPORT (GUIDE RING ~)	ZBR34290										1 pc 1 pc
	483	CHAMBER (UPPER ~ WITH DIFFUSER)KIT	486 308	CONICAL SPRING CHAMBER (UPPER ~ WITH DIFFUSER)	ZBR33510										1 pc 1 pc
	484	RECYCLING PLUG KIT	6 86 87 476	GASKET (FILL/DRAIN PLUG ~) PLUG (RECYCLING ~) O-RING (SHUTTER ~) BUSHING	ZBR33520										1 pc 1 pc 1 pc 1 pc

Ricambi validi per i modelli con codice E4Axxxxx /E4Dxxxxx, per i modelli dove in etichetta non è presente alcun codice prodotto contattare il ns. ufficio Post-Vendita
Spare parts valid for models E4Axxxxx/E4Dxxxxx. For models which in label is not indicated Part number, please contact our After Sales
Pièces détachées valables pour les modèles E4Axxxxx/E4Dxxxxx. Pour les modèles pour lesquels il n'y pas d'indication, veuillez contacter notre Service Après Vente
Ersatzteile gültig für Modelle mit Artikel Nummer E4Axxxxx /E4Dxxxxx Für Modelle, die kein Artikel Nummer, bitte nehmen Sie Kontakt mit unser Service Büro

				DRW. DR090004 VLR 2/4 DRW.DR090010 VLRI-X 2/4 DRW.DR090006 VLR 8/16 DRW.DR00016 VLRI-X 8/16	SPARE-PARTS			
				Select language English	SPARE-PARTS KIT TABLE			
SPARE-PARTS				VLR 2/4-VLRI-X 2/4 VLR 8/16-VLRI-X 8/16	PUMP MODEL			
RECOMMENDED PARTS KIT	KIT REF. Nr.	KIT DESCRIPTION	COMPONENT REF. Nr.	COMPONENT DESCRIPTION	VLR 2/4	VLRI-X 2/4	VLR 8/16	VLRI-X 8/16
	201	GASKET KIT VITON	5	PLUG (FILL ~)	1 pc	0 pc	2 pc	0 pc
			6	GASKET (FILL/DRAIN PLUG ~)	0 pc	0 pc	1 pc	2 pc
			25	O-RING (PUMP BODY ~)	2 pc	2 pc	2 pc	2 pc
			78	NOZZLE (AIR ~)	1 pc	1 pc	1 pc	1 pc
			87	O-RING (SHUTTER ~)	1 pc	1 pc	1 pc	0 pc
			333	PLUG (SIDE ~)	0 pc	0 pc	1 pc	0 pc
			412	GASKET	1 pc	0 pc	0 pc	0 pc
	371	MECHANICAL SEAL KIT Q1BVGG	266	SEAL (STATIONARY ~)	ZBR36950		1 pc	1 pc
			267	SEAL (ROTATING ~)			1 pc	1 pc
			482	ADJUSTMENT SPACER			1 pc	1 pc
	371	MECHANICAL SEAL KIT U3U3EGG	266	SEAL (STATIONARY ~)	ZBR36970		1 pc	1 pc
			267	SEAL (ROTATING ~)			1 pc	1 pc
			482	ADJUSTMENT SPACER			1 pc	1 pc
	371	MECHANICAL SEAL KIT U3U3VGG	266	SEAL (STATIONARY ~)	ZBR36980		1 pc	1 pc
			267	SEAL (ROTATING ~)			1 pc	1 pc
			482	ADJUSTMENT SPACER			1 pc	1 pc
	371	MECHANICAL SEAL KIT Q1Q1EGG	266	SEAL (STATIONARY ~)	ZBR36940		1 pc	1 pc
			267	SEAL (ROTATING ~)			1 pc	1 pc
			482	ADJUSTMENT SPACER			1 pc	1 pc
	371	MECHANICAL SEAL KIT Q1Q1VGG	266	SEAL (STATIONARY ~)	ZBR36960		1 pc	1 pc
			267	SEAL (ROTATING ~)			1 pc	1 pc
			482	ADJUSTMENT SPACER			1 pc	1 pc
	484	RECYCLING PLUG KIT VITON	6	GASKET (FILL/DRAIN PLUG ~)	0 pc	0 pc	1 pc	2 pc
			86	PLUG (RECYCLING ~)	0 pc	0 pc	1 pc	2 pc
			87	O-RING (SHUTTER ~)	1 pc	1 pc	1 pc	0 pc
			88	SHUTTER	1 pc	1 pc	0 pc	0 pc
			412	GASKET	1 pc	0 pc	0 pc	0 pc
			476	BUSHING	1 pc	0 pc	1 pc	0 pc

NOTE

FACE MATERIAL (Item 1/2)
Q1=Silicon carbide
B=Carbon graphite
U3=Tungsten carbide

SECONDARY SEAL COMPONENTS (Item 3)
E=EPDM
V=Fluorcarbon rubber (VITON)

SPRING AND COSTRUCTION MATERIALS (ITEM 4/5)
G=CrNiMo steel
G=CrNiMo steel

				DRW. DR100023_00	SPARE-PARTS													
				Select language English	SPARE-PARTS KIT TABLE													
SPARE-PARTS				VLR32	PUMP MODEL													
RECOMMENDED PARTS KIT	KIT REF. Nr.	KIT DESCRIPTION	COMPONENT REF. Nr.	COMPONENT DESCRIPTION	VLR32-1 F T	VLR32-2 F T	VLR32-3 F T	VLR32-4 F T	VLR32-5 F T	VLR32-6 F T	VLR32-7 F T	VLR32-8 F T	VLR32-9 F T	VLR32-10 F T	VLR32-11 F T	VLR32-12 F T	VLR32-13 F T	VLR32-14 F T
	82	TIE ROD KIT (PUMP BODY -)	334 214 97 4 158 165 102 105 107 109 237 274 417 78 6 228 25 333 21 73 319 273 276 277 9	ROD WASHER NUT (TIE ROD LOCKING -) SCREW SCREW (STOP -) WASHER (BEARING LOCK -) SCREW (SEAL HOLDER FLANGE -) SCREW REW (MOTOR LOCKING - / INTERNAL SUPPO NUT (MOTOR LOCKING -) SCREW (COUPLING -) GUARD COUPLING SCREW PIN NOZZLE (AIR -) GASKET (FILL/RAIN PLUG -) GASKET (ANTI-VIBRATION -) O-RING (PUMP BODY -) PLUG (SIDE -) IMPELLER NUT BUSHING (CONIC -) RING (STOP -) RING (GUIDE -) SUPPORT (GUIDE RING -) DIFFUSER	ZBR34880 4 pc 4 pc 4 pc	ZBR33580 4 pc 4 pc	ZBR33600 4 pc 4 pc	ZBR34370 4 pc 4 pc	ZBR34920 4 pc 4 pc	ZBR34930 4 pc 4 pc	ZBR34940 4 pc 4 pc	ZBR34950 4 pc 4 pc	ZBR33670 4 pc 4 pc	ZBR34970 4 pc 4 pc	ZBR34980 4 pc 4 pc	ZBR34990 4 pc 4 pc	ZBR35000 4 pc 4 pc	ZBR35010 4 pc 4 pc
	200	BOLTS AND SCREWS KIT	4 158 165 102 105 107 109 237 274 417 78 6 228 25 333 21 73 319 273 276 277 9	SCREW (STOP -) WASHER (BEARING LOCK -) SCREW (SEAL HOLDER FLANGE -) SCREW REW (MOTOR LOCKING - / INTERNAL SUPPO NUT (MOTOR LOCKING -) SCREW (COUPLING -) GUARD COUPLING SCREW PIN NOZZLE (AIR -) GASKET (FILL/RAIN PLUG -) GASKET (ANTI-VIBRATION -) O-RING (PUMP BODY -) PLUG (SIDE -) IMPELLER NUT BUSHING (CONIC -) RING (STOP -) RING (GUIDE -) SUPPORT (GUIDE RING -) DIFFUSER								ZBR34890 4 pc 4 pc 4 pc 4 pc 4 pc 4 pc 4 pc 4 pc 4 pc 1 pc						